

Vammmas

BY HAGIE
UpFront



**OPERATOR and SERVICE MANUAL
FOR
VAMMAS PS4200 PLOW
HAGIE MANUFACTURING COMPANY**

721 CENTRAL AVENUE WEST
BOX 273
CLARION, IOWA 50525-0273

(515) 532-2861

MANUAL FOR MODEL YEAR 2007
04-08 A010408EN

VAMMAS Plow Sweeper PS 4200

Operator and Service Manual

1.	FOR THE OPERATOR	1
2.	OPERATOR RESPONSIBILITIES	2
3.	SAFETY	3
	3.1. Warning symbols	3
	3.2. Safety instructions	4
	3.3. Risk factors	6
	3.4. Danger zones	6
	3.5. Warning symbols	6
4.	INTRODUCTION	7
	4.1. External dimensions	7
	4.2. Plow	8
	4.3. Brushes	8
	4.4. Hydraulic system	9
5.	OPERATING THE MACHINE	10
	5.1. Connecting the plow sweeper to the machine	10
	5.2. Disconnecting from the machine.....	12
	5.3. Daily inspections	13
	5.4. Operating the plow sweeper	18
	5.4. Using the plow controls	19
6.	SPECIFICATIONS.....	20
7.	TIGHTENING TORQUES FOR BOLTS AND SCREWS.....	21
8.	ELECTRICAL CIRCUIT	22
9.	HYDRAULIC DIAGRAM	23
10.	DECOMMISSIONING	24
11.	CONTACT INFORMATION.....	25
12.	SPARE PART LIST– VAMMAS	27
	12.1. Instructions for spare part manual readers	25
	P099122-1 PLOW SWEEPER	33 (A3)
	* P099232-2 GUIDE BAR	35 (A5)
	** P099122-2 BRUSH	37 (A7)
	* P099246-2 REGULATING UNIT, VERTICAL LEVER	39 (A9)
	* P094965-2 REGULATING UNIT, HORIZONTAL LEVER	41 (A11)
	* P099291-1 EXTRA PLOW (EXTRA)	43 (A13)
	* 4286246 CYLINDER	45 (A15)
	* 4286245 CYLINDER	47 (A17)
	P099133-2 SWEEPER AXLE	49 (A19)
	P099230-1 SKID ASSEMBLY.....	51 (A21)
13.	SPARE PART LIST– HAGIE.....	52
	Snow plow quick coupler.....	52
	Broom speed valve.....	53
	Control valve assembly	54
	Electric panel assembly	55
	Snow plow lift arm assembly.....	56
	FAX PAGES.....	57

1. TO THE OWNER



FOR THE OPERATOR

Thank you for choosing Vammas by Hagie PS 4200 plow!

This operator's manual is intended for both beginners and experienced operators. It is recommended that, before starting to operate the machine, the operator read this operator's manual to master the efficient and economic use of the machine, even if the operator has worked with an equivalent machine previously.

The principles introduced in this manual apply to the use of this machine only. The persons responsible for airfield maintenance are also responsible for properly adapting these principles for practical use.


The information contained in this manual is based on the facts available at the time of its compilation. This manual is intended for operators of Vammas by Haige equipment only. Reproducing the manual in any form without prior authorization from Patria Vammas by Hagie is strictly prohibited.



Identification plate

The machine's identification plate is located in the frame, on the right side of the machine, as indicated in the figure.

2. OPERATOR RESPONSIBILITIES



Before starting to use the machine, familiarize yourself with the contents of this manual, paying special attention to the SAFETY section, regardless of whether or not you have previously operated similar equipment.

The operator of the driving machine bears the primary responsibility for the maintenance and safe use of the equipment. To ensure proper and effective functioning of the machine, the instructions provided in this manual must be followed carefully. This is also required for the guarantee to be valid.

The safety instructions contain a summary of the instructions and rules that must be followed whenever working with the machine. However, these instructions do not replace the various statutory occupational and traffic safety requirements that may be in force on different sites.

Everything possible has been done to ensure that the information contained in this manual is correct and that the manual contains all necessary warnings. Vammas by Hagie does not assume any direct or indirect liability for damages caused by the information contained in this manual or lack of any warnings issued therein.

Neither Vammas by Hagie nor its representatives are liable for any form of damage caused by the use of their tools or components.

Due to constant product development, Vammas by Hagie reserves the right to alter any machine function or structure after the publication of this manual.

3. SAFETY

3.1. Warning symbols

The following warning symbols are used in this manual to emphasize points of great importance, which are to be noted.

Injury risk




Neglecting the safety measures may cause serious injury or death.

Equipment damage or environmental risk




Incorrect operation or servicing of the machine may cause damage to the environment or to the machine itself.

Note



Pay attention to specific instructions.

References



Consideration for the environment when using the machine.

3. SAFETY

3.2. Safety instructions



DANGER

Read and familiarize yourself with all warnings and safety instructions specified in this manual.



DANGER

The machine may not be operated, repaired or serviced by a person, who is unqualified, tired, ill or intoxicated.



DANGER

The operator of the machine is always responsible for safety. The operator must have adequate training on the machine and its operation.



DANGER

Keep a first-aid kit at hand at all times. Check the contents of the first-aid kit regularly and update the contents if necessary.



DANGER

When moving, the machine may cause personal injury in the operating area. During operation, no person is to stay in the operating area, on top of, or on the steps or platforms of the machine.



DANGER

Do not step between the coupling and the wheel loader when connecting.



DANGER

Check that there are no persons under the equipment when lowering it.



DANGER

Danger of clamping!

- Space between the coupling and the wheel loader
- Brushes
- Opening wedge part and its opening mechanism



DANGER

Never service or repair the machine alone.



DANGER

When working under the machine, make sure that it is securely and safely supported. Danger of clamping!


3. SAFETY



Do not allow unauthorized persons inside the loader cabin when you are servicing the machine.



When making adjustments to the machine, adhere to the given instructions and settings. Appropriate use of the machine increases its service life.



Always use original spare parts and components.



Keep in mind the following facts and hazards associated with high pressure hydraulics:

- Use protective clothing and goggles when servicing the hydraulic system.
- The hydraulic system is under high pressure.
- Escaping high-pressure oil may penetrate the skin and cause severe injuries and accidents. The oil spray can be very difficult to detect.
- Oil operating temperature can be very high.
- The hydraulic system must be depressurized before it can be opened.
- Before servicing, ensure that the machine has been lowered and that the cylinder is in a static state.
- Clean all connections and components, and store the system free of impurities.
- Check the tightness of hose connections. Replace worn or damaged hoses. New hoses must meet the requirements set by Vammas by Hagie.
- Do not discard oil into the environment! 



If welding is necessary, take the following precautions:

- Remove the battery cables of the loader before welding.
- Always use a welding mask and protective clothing.
- Be careful not to become part of the welding electrical circuit.
- Always keep fire-extinguishing equipment close at hand.
- Welding gases are hazardous to health; do not breath in the gases.

3. SAFETY

3.3. Risk factors

Personal injury risks



- Insufficient training on correct use of the machine
- Unauthorized persons in the operating area
- Negligence of occupational safety regulations

Equipment damage risks




- Negligence of operating and service instructions
- Incorrect operation of the machine

3.4. Danger zones





Minimum safety distance from the machine during operation is 5 meters (17 ft) !

3.5. Warning symbols



The adjacent figure shows the location of the warning symbols with arrows. The upper arrows indicate the location of the symbols; the symbols are located on the coupling side.




Clean dirty warning symbols, replace them when necessary.

4. INTRODUCTION



The plow sweeper is designed for plowing and cleaning airport lights located on the ground. The plow opens at the wedge. When approaching the light, the wedge is opened using a hydraulic cylinder and the brushes behind the wedge clean the light. Once the light is cleaned, the wedge is closed. The distance between the lights is plowed normally with the plow wedge closed.


4.1. External dimensions



* note that some of the drawings and pictures may not depict the plow as it is used by Hagie Manufacturing*

4. INTRODUCTION

4.2. Plow



The plow is a conventional wedge plow by construction, except for the opening wedge part.

Wings

Replaceable blades have been attached to the bottom edge of the plow wings (1). The blades enable snow and slush to be removed efficiently. At the same time, the blades protect the plow wings from wearing.

Wedge part

The wedge part (2) is constructed from two wings. The wings are articulated so that they can be spread into an open position. The wedge part is also equipped with replaceable blades.

Coupling

The plow is equipped with a quick coupling. The coupling is attached to the frame, slightly to the side of the machine's centerline, so that the wedge part of the plow is visible from the loader cabin.

4.3. Brushes




There are two brushes attached to the plow frame, inside the wings. The brushes can be adjusted vertically and horizontally, and they can also be tilted. This is necessary in order to ensure efficient brushing as the brushes wear down. Exhausted brushes can be replaced.

4. INTRODUCTION

4.4. Hydraulic system

The plow sweeper hydraulic system is based on the hydraulics of the tractor. When connecting the plow, the pressure and tank hoses are connected. These hoses are equipped with quick couplings.



Operating principle

The plow sweeper is operated using the hydraulics of the machine. The oil flow generated by the machine is operated proportionately with on/off and speed controls manipulated by the operator.

The electro-hydraulic control valve is used for controlling the wedge and the brush distances when directing the oil for use in the cylinders. The system allows the brushes to operate during opening of the wedge, and operation can continue without stopping.

The flow control valve (broom speed valve) is used for operating the hydraulic motors for brush operation. The motors are connected in a series so that they rotate in opposite directions.

The relief valves on the lift cylinders are set at 1500-1800psi.

All plow functions are electronically controlled by the operator from inside the cab.



5. OPERATING THE MACHINE

5.1. Connecting the plow to the tractor



Hagie GST20 Attachment Change-over Instructions

Boom to Edge Light Plow

1. Set the machines parking brake
2. Fold the booms out half way*
3. Lower the boom to a height accessible from the ground*
4. Lower the boom support stands*
5. Disconnect the solution hose to the boom*
6. Cap and plug the hose and connection *
7. Pull the quick connect pins and lock them open*
8. Lower the booms to the ground and continue lowering the booms until the lift arms are free from the machine*
9. Shut machine off*
10. Disconnect the hydraulic connection*
11. Disconnect electrical connection*
12. Start machine*
 - 3 warnings will sound for "modules off line" (Accept the warnings)-
13. Release parking brake*
14. Back away from the booms slowly*



Hydraulic connection



Electrical connection


*see the GST 20 Operator Manual for more detailed instructions

5. OPERATING THE MACHINE


15. Line up to the plow and approach until the lift assembly begins to engage the machine
16. Set the parking brake
17. Shut machine off
18. Connect the hydraulic connection
19. Connect the electrical connection
20. Start machine
 - 3 warnings will sound for “module off line” (Accept the warning)
21. Raise the plow making sure the hooks on the lift assembly engage the tractor completely
22. Release the quick connect pins (make sure they fully engage)
23. Connect the support ratchets to the machine
24. Check that all functions are working properly



Raise the plow



Make sure the hooks are fully engaged



Connect the support ratchets

5. OPERATING THE MACHINE

5.2. Disconnecting the plow from the tractor



Hagie GST20 Attachment Change-over Instructions

Edge Light Plow to Boom

1. Set the machines parking brake
2. Disconnect the lower support ratchets from the machine
3. Pull the quick connect pins and lock them open
4. Lower the plow to the ground and continue lowering until the lift arms are free from the machine
5. Shut machine off
6. Disconnect the hydraulic connection
7. Disconnect electrical connection



8. Start machine
*3 warnings will sound for “modules off line” (Accept the warnings)
9. Release parking brake
10. Back away from the plow slowly
11. Line up to the boom and approach until the lift assembly begins to engage the machine*
12. Set the parking brake*
13. Shut machine off*
14. Connect the hydraulic connection*
15. Connect the electrical connection*
16. Start machine*
17. Raise the boom making sure the hooks on the lift assembly engage the machine completely*
18. Release the quick connect pins (make sure they fully engage)*
19. Connect the solution hose to the boom*
20. Raise the boom support stands*
21. Check that all functions are working properly

*see the GST 20 Operator Manual for more detailed instructions

5. OPERATING THE MACHINE

5.3. Daily inspections

The following checks must always be carried out before operating the machine. These checks should also be repeated at the end of the working day. This way any fluid leaks and damages can be detected more quickly and service and repair procedures can be planned well in advance.

1. Check the condition of the structures

Check the following:


- Welded seams
- Tightness of bolts and nuts
- Possible wear
- Corrosion damage
- General structure of the machine

2. Check the wear of the brush bristles

The bristles are made of a plastic compound and they wear down. Operating efficiency and results suffer if an over worn brush is used. Replace the brush cassettes when they are worn and the length of the bristles is at least 4 inches.

Replacement

- Lift the plow sweeper up and place a support under the plow.
- Lift the brushes up and turn them to the rear position.
- Open the retaining bolts located in the middle of the bristles.
- Replace the brush cassettes and check the operation of the brushes.



5. OPERATING THE MACHINE

3. Check the adjustments

The plow sweeper must be adjusted before use. With appropriate adjustments, the quality of work is improved and unnecessary damage caused by wear is prevented.

Adjustments:


- Plow floating.
- Wing blades.
- Plow height.
- Brush height.
- Brush tilt.
- Brush distances.



Plow floating

Test the plow and its floating. The plow is “floating” when the FLOAT switch has been activated. It simply means that the plow is in an automatic operational status and will make minor correctional adjustments on its own. Although the plow is being operated automatically, you may still make corrections manually.

The plow can be adjusted horizontally from the cab using the lift and level functions.



Wing blades

The wing blades are made from wear resistant steel. However, the blades wear in time. Lower the blades by adjusting the location of the mounting holes .

5. OPERATING THE MACHINE



Plow height

It is possible to adjust the plow sweeper's height from the ground. The height is adjusted according to the desired plowing precision. The runners (4pcs) must be adjusted so that they support the plow slightly above the surface of the ground. This way the plow does not grind against small irregularities on the ground, and plowing does not excessively wear the wing blades.

Adjustment is done manually by turning the trapezoid screws (1&2) of the adjustment runners, located on the inside of the plow wings and the inside rear corners of the stationary blade. Adjustment should be made when the plow is slightly off the ground, which makes it easier to turn the screws.




Brush height

The ground clearance of the brush is adjusted by turning the trapezoid screw (3). The right clearance is best found by testing, but it is good to remember that the brush should not be set too low. This wears down the bristles quickly and strains the hydraulic motors.

Brush tilt

The brush tilt (4) is adjusted in the same way as the brush height. These adjustments should be made at the same time, and tested. The brush should be tilted forward as this gives the best results



Brush distances

The brush distances (below) are adjusted to the desired setting hydraulically from inside the cab. The brush distances are also adjusted as the bristles wear. The brushes must not be set too close to each other as this results in excessive wear and may also damage the motor bearings. Neither should they be set too far apart as they wear down when they hit the inner edge of the plow wings.





WARNING

Incorrectly adjusted brushes load the hydraulic motors and wear down the brush.

5. OPERATING THE MACHINE



4. Check the sight bars



With the help of the sight bars, plowing can be performed in a straight line and the wedge part can be accurately directed at the lights.

The plow coupling is located slightly to the left of the centerline so as to allow the operator to better see the plow's wedge part. Due to the location of the coupling, the sight bars can also be adjusted. The rear sight bar can be moved sideways to the desired location. The sight bars are adjusted after which they can be used for accurately defining the driving direction.



5. Check the hydraulic system

The hydraulic system must be checked. Leaks can result in inaccuracies in the controlling of the system. It is also advisable to check the condition of the electric valve control cable and the cleanliness of the connections.

Inspect:


- Hydraulic hoses and connections.
- Hydraulic valves.
- Hydraulic motors.
- Cylinders.

5. OPERATING THE MACHINE

6. Perform manual greasing

Apply grease on the grease nipples at least once a week. Greasing prevents wearing of the joints and increases the service life of the components.

The total number of grease nipples in the machine is 21.




The Hagie lift arm has a grease zerk in each level cylinder shaft. They are located on the right hand side of each shaft.




5. OPERATING THE MACHINE

5.4. Operating the plow sweeper



The operator must check that the ground clearance of the loader is greater than the height of the lights to be cleaned.



When operating the machine, all regulations and laws governing airports must be adhered to.



When using the plow sweeper, care must be taken to ensure the plow wings do not damage the items being cleaned. It is advisable to practice operating the machine.

Once the plow sweeper is connected to the machine and the necessary adjustments and lubrications have been made, the machine is ready for operation.

Starting and operating the machine

Once the hydraulics have been connected and the WORK MODE and FLOAT switches have been engaged, the brushes begin to rotate and operation can begin. Adjust the brush speed with the dial on the side of the console. Drive along the direction of the row of lights using the sight bars as guidance. When approaching the first light, use the directional control valve control button to open the wedge. You can drive over the light as usual. The brushes clean the base of the light. When the wedge part of the plow has passed the light and the light is at the brushes, use the control button to close the wedge part. Continue plowing towards the next light and repeat the procedure. It is advisable to stop the rotation of the brushes when plowing between the lights especially if the lights distance is long. This saves the brushes from wear. To shut the brushes off, press the button at the bottom of the control lever.

5. OPERATING THE MACHINE

5.5. Using the plow controls



Hagie GST20 Edge Light Plow Controls

To activate ALL the plow controls you must first have the GST in “work mode” by turning on the WORK MODE switch on the right side console.* The machine must be stopped for any mode change to take effect.

The plows functions are controlled primarily via the hydrostat handle. *

Raise and lower plow:

To raise or lower the plow, rock the switch at the top of the face on the handle. (1) Pushing forward raises the plow, pulling lowers the plow.

Tilt the plow:

To manually tilt the plow forward or backward, rock the round switch on the left or right hand side of the face on the handle up and down. (2 & 3) Pushing forward lowers the front plow tip, pulling back raises the front plow tip.

Adjust brushes:

To increase (open) or decrease (close) the brush width, rock the switch on the left hand side on the face of the handle left or right. (2) Pushing right narrows the brushes, pushing left widens the brushes.

Open and close plow doors:


To open or close the front of the plow, rock the switch on the right side of the face of the handle to the left or right. (3) Pushing right will open the plow, pushing left will close the plow.

Activate the brushes:

To turn the brushes on or off, press the button at the bottom of the face on the handle. (4) The green light in the front center of the headliner will light when the brushes are active. You can adjust the brush speed by turning the speed control knob on the left side of the console next to the hydrostat handle.

To use the plow:

Turn on the FLOAT switch on the side console, make sure WORK MODE switch is on, lower the plow close to, or on the ground, and turn the brushes on by pressing the button on the handle. This activates the float and will lower the plow and allow it to tilt as it rides along the ground. You can manually assist the plow down once the brushes are active. The float is only activated when the brushes are turning and the float switch is on. As you approach a edge light, rock the switch to open the plow and, if needed, adjust the brush width to clear the snow away from the light. Once the light has cleared the plow doors, rock the switch to close the plow again.



6. SPECIFICATIONS

PRINCIPAL DIMENSIONS		
Operating width	12ft 11in	4253mm
Transport width	16ft 2in	4930mm
Length*	9ft 5in	2871mm
Height*	6ft 5in	1964mm
Wing height (at the rear)	4ft 2in	1280mm
Weight*	4740 lbs.	2150 kg
GENERAL		
Coupling	Multifaster Mobile quick coupling	
Plow frame	Welded from steel plates and profiles	
Plow wing blades	4 detachable blades	
Brushes	(2) 2x10 replaceable brushes	
HYDRAULIC SYSTEM		
Oil flow	15.85 g/m max brushes only	60 l/m
Max. pressure	210 bar	
Rotation rate of hydraulic engines	250 rpm	
LUBRICANT AND MEDIUM RECOMMENDATIONS		
Hydraulic oil	Mobil Fluid 424	
Grease lubrication	EP general grease	


* the measurements are for the plow only, they do not include the lift arm assembly

7. TIGHTENING TORQUES

If there are any special requirements related to bolt and screw torques, they are specified in Parts List and Manufacturer's Manuals. The table below shows general torques applicable to all other bolts and screws. Maximum tolerance is $\pm 10\%$ of given torque.

Tightening torques for bolts and screws				
Torque Nm (1Nm ~ 0.1kpm ~ 0.74lb-ft)				
Thread	Strengt			Key span
	8.8	10.9	12.9	
M 6	10.3	14.7	17.6	10
M 8	25.5	35.3	42.1	13
M 10	50.0	70.6	85.3	17
M 12	87.3	122.6	147.1	19
M 14	130.3	194.2	235.4	22
M 16	210.8	299.1	357.9	24
M 18	289.3	411.9	490.3	27
M 20	411.9	578.6	696.3	30
M 22	559.0	784.5	941.4	32
M 24	711.0	1000	1196	36
M 27	1049	1401	1775	41
M 30	1422	2010	2403	46
M 33	1932	2716	3266	50
M 36	2481	3491	4197	55

8. HYDRAULIC DIAGRAM



1	1	606283	PLDW CTRL VALVE, SAUER	07	24	1	616611	06-451TC-06FJX-06FJX-91	H/A
2	1	618803	MULTIFASTER MOBILE		25	1	616612	06-451TC-06FJX-06FJX-109	H/A
3	4	621558	LEVEL CYL, 3.00 X 11.00	STS	26	1	616613	06-451TC-06FJX-06FJX-125	H/A
4	2	606214	RELIEF VALVE ASSY		27	1	616614	06-451TC-06FJX-06FJX-145	H/A
5	1	606253	CTRL VALVE, SOLU PUMP	SAUER	28	1	616615	06-451TC-06FJX-06FJX-153	H/A
6	2	611125	3/4MJIC-3/4MDR ADPTR		29	1	616616	06-451TC-06FJX-06FJX-159	H/A
7	12	618119	9/16MJIC-90-9/16MDR LBD		30	1	616617	06-451TC-06FJX-06FJX-168	H/A
8	6	618126	9/16MJIC-9/16MDR ADPTR		31	1	616618	06-451TC-06FJX-06FJX-183	H/A
9	1	618327	3/4MJIC-7/8MDR ADPTR		32	1	616619	06-451TC-06FJX-06FJX-191	H/A
10	6	618629	9/16MDR BRANCH TEE-9/16MJIC		33	1	616620	06-451TC-06FJX-06FJX90-30	H/A
11	2	618634	9/16MJIC-45-9/16FJIC SWIV LBD		34	1	616621	06-451TC-06FJX-06FJX90-37	H/A
12	1	618637	7/8MDR BRANCH TEE-7/8MJIC		35	1	616622	06-451TC-06FJX-06FJX90-42	H/A
13	2	618734	9/16JIC .047 DRIFICE ADPTR		36	1	616623	06-451TC-06FJX-06FJX90-47	H/A
14	4	611127	1 1/16MJIC-1 1/16MDR ADPTR		37	1	616624	06-451TC-06FJX-06FJX90-116	H/A
15	1	618109	9/16MJIC-3/4MDR ADPTR		38	1	616625	06-451TC-06FJX-06FJX90-126	H/A
16	2	618308	1 1/16MJIC-1 5/16MDR ADPTR		39	1	616626	06-451TC-06FJX-06FJX90-175	H/A
17	1	618486	9/16FJIC SW RUN TEE-9/16MJIC		40	1	616627	08-451TC-08FJX-08FJX90-31	H/A
18	1	618487	1 1/16FJ SW RUN TEE-1 1/16MJ		41	1	616628	08-451TC-12FJX-08FJX90-42	H/A
19	1	618249	3/4MJIC-90-9/16MDR LBD		42	1	616629	10-451TC-08FJX-10FJX90-125	H/A
20	1	618425	9/16MJIC-45-9/16MDR LBD		43	2	616630	10-451TC-12FJX-12FJX90-85SLH/A	
21	1	616582	06-451TC-06FJX-06FJX90-51	H/A	44	1	616631	10-451TC-12FJX-12FJX-86 SL	H/A
22	1	616609	04-451TC-06FJX-06FJX-42	H/A	45	1	616632	12-451TC-12FJX-12FJX-84	H/A
23	1	616610	04-451TC-06FJX-06FJX-88	H/A	46	1	616633	12-451TC-12FJX-12FJX-86	H/A
					47	1	616634	08-451TC-06FJX-10FJX-22	H/A

10. DECOMMISSIONING

The end user of the machine is responsible for its decommissioning. If the end user does not have the ability or the resources to disassemble the machine, the work must be performed by someone who does possess the necessary knowledge and skills. In disposing of the waste material from disassembly of the machine, the following matters should be considered:

- The machine body, all the steel constructions, and the copper and aluminum in the electrical wiring are recyclable. The metals can be melted and used as raw material for new products, except for machine parts that have been in contact with substances that are regarded as hazardous waste. The contaminated parts can usually be simply cleaned or rinsed, after which they can be recycled.
- Most plastic parts are recyclable, similarly to the metals. Each plastic part carries information on the material used and a manufacturing date, which can be used for determining whether the part can be recycled.
- Rubber parts are not regarded as hazardous, and they can be disposed of according to normal procedures. Tubes (hydraulics etc.) must be cleaned before they are disposed of. Worn-out tires can be returned to the dealer from whom they were originally bought.
- Windshields and other cabin windows are not accepted for conventional glass recycling, but they can be disposed of via normal waste disposal methods.
- Electrical components that are classified as hazardous waste (accumulators, batteries, circuit boards) and other hazardous waste must be delivered to a licensed waste treatment location or be disposed of according to local regulations.
- Air conditioning units, which contain CFC and HCFC compounds, must always be delivered for treatment to a licensed waste disposal facility.
- For disposal instructions for fluids and lubricants, check your state or federal guidelines.

These instructions are not binding, but they offer suggestions for appropriate waste disposal procedures. Local authorities always have more detailed instructions and recommendations on the disposal of different materials.



When removing a machine from use, you must always follow the relevant authorities' regulations on waste disposal that are in force at the time and location of disassembly.

11. CONTACT INFORMATION

Hagie Manufacturing Company

721 Central Avenue West

PO Box 273

Clarion, Iowa 50525-0273

Phone: 1 (800) 247-4885


Fax: 1 (515) 532-3553

E-mail: www.hagie.com

Notes:

Notes:

12. SPARE PARTS LIST– VAMMAS



All dimensions given in the drawings are in millimeters unless specified (1"= 25.4mm)

12.1. Instructions for spare part manual readers

The spare part manual is compiled to make ordering of spare parts easier and faster for our customers. The contents of the spare part manual have been compiled to correspond with the structure of the machine delivered. However, continuous product development may cause modifications to the machine and the appropriate spare part manual.


Always include the following data when ordering spare parts:

1. Type and serial number of the machine (e.g., PSB 4500, Serial No. 001). The data can be found in the machine identification plate located on the frame of the machine. If the part to be ordered is, for example, a hydraulic motor gasket, it is advisable to also attach to the order the type plate data from the appropriate motor.
2. Part code (spare part number), name, and required quantity.
3. Date of the spare part manual.
4. Exact shipping address and method of delivery.
5. Name and invoicing address of the orderer.
6. Order number, if used.

In ambiguous cases, consult the dealer for help in selecting the correct part.


12. SPARE PARTS LIST– VAMMAS

Viewing a spare parts drawing




Spare part drawing

- (A) Assembly name.
- (B) Assembly number (code). The letter at the end indicates the version of the drawing.
- (C) Date of compilation of the spare part manual.
- (D) Manufacturer of the machine.
- (E) Drawing with reference numbers.




Views and directions

The different views use the so-called one-turn method. This is a European standard (previously the E method).



Line types

- Visible form and outlines.
- Invisible form and outlines.
- Center lines (symmetry lines) and trajectories.
- Cross-section lines.
- Alternate or extreme positions of moving parts (double dotted lines).



Cross-section views and detail diagrams

In a cross-section view, the components are viewed as having been cut through from a certain location (A-A). The viewing direction is indicated by an arrow.

12. SPARE PARTS LIST– VAMMAS

List of spare parts

Patria				
28.12.2004				
No	Code	Qty	Name	Description
P094650-0J		*SWEEPER ASSEMBLY		A13
0	P091874-2	2	CYLINDER PIN	[A19]
7	P091871-3	2	SPACER SLEEVE	
8	P091893-4	6	ARM CASTOR WHEEL	
9	P097821-3	2	SPRING RETAINER	
10	P095569-0	2	ROTATING PIECE	
11	P095613-2	2	COVER	
12	P091865-4	2	BRACKET	
13	P091869-0	2	PIN	
14	P091883-3	2	PLAIN BEARING	
15	P093476-4	8	ADJUSTING ROD	
16	P092800-3	2	PIN	
17	P091882-3	2	BUSHING	
18	P091881-4	4	AXLE	
19	P091147-3	2	NUT	
20	P091856-2	4	WASHER	
21	P091858-4	4	WEDGE	
22	P091857-4	4	PLAIN BEARING	
23	4283831	4	SEALING	
24	4280858	4	SEALING	
25	4282863	2	SEALING	
26	4273368	8	CONICAL ROLLER BEARING	
27	4278117	2	CONICAL ROLLER BEARING	
28	4278005	2	SAFETY ISLAR	
29	0011912	2	AXLE NUT	
30	4273487	4	SEALING	
31	4276498	4	WHEEL DISC	
32	4281622	4	TYRE	
33	P096470-4	40	SCREW	M14 X 25 M8.8
34	P098874-2	1	COVER, LEFT	
35	P098875-2	1	COVER, RIGHT	
36	4286003	2	HYDRAULIC MOTOR	F11-150-PM-CV SR.NO. 428
37	4283832	2	PLAIN BEARING	
38	4286038	2	DRAW SPRING	
39	4272655	4	CROWN NUT	M30 X 1.5 DIN 935 M 8 -ZNS
40	4277498	4	SPLIT PIN	0.3 X 50 DIN 94-ZNS-ST
41	4282028	6	HEX NUT	M24 X 2 OF S2000 M 8-ZNS
42	4282829	4	ALLEN SCREW	M16 X 100 DIN 912 8.8-ZNS
43	0034927	4	WASHER	17 SF S2041-ZNS
44	4272628	12	LOCK NUT	MM16 DIN 985 M 8 -ZNS
45	0008376	8	HEX SCREW	M16 X 70 ISO 4017 8.8-ZNS
46	0007413	8	HEX SCREW	M8 X 20 ISO 4017 8.8-ZNS
47	0007962	8	WASHER	8.4 SF S2041-ZNS

Copyright 2004 Patria Vammas Oy

- ① Assembly number (code). The letter at the end of the code (if shown) indicates the version of the part list.
- ② Assembly name.
- ③ Reference number.
- ④ Spare part code.
- ⑤ Quantity or length in meters (0.9 m).
- ⑥ Part name.
- ⑦ Part description / identifier. Indicates the identifier of a standard part. The part description column may include marking [A19]. This means that the part has a separate spare part drawing and list in a place indicated by the marking.
- ⑧ Page code.

12. SPARE PART LIST– VAMMAS

This page intentionally left blank.

12. SPARE PART LIST– VAMMAS

Patria

11.11.2005


SPARE PART LIST		A
P099122-1 PLOW SWEEPER.		A3
* P099232-2 GUIDE BAR.		A5
** P099122-2 BRUSH		A7
* P099246-2 REGULATING UNIT, VERTICAL LEVER		A9
* P094965-2 REGULATING UNIT, HORIZONTAL LEVER		A11
* P099215 2 SUSPENSION		A13
* P099291-1 EXTRA PLOW (EXTRA)		A15
* 4286246 CYLINDER		A17
* 4286245 CYLINDER		A19
P099133-2 SWEEPER AXLE		A21
P099230-1 SKID ASSEMBLY.		A23

12. SPARE PART LIST- VAMMAS

Patria

PLOW SWEEPER P099122-1

11.11.2005



12. SPARE PART LIST– VAMMAS

Patria

11.11.2005


No	Code	Qty	Name	Description
P099122-1			PLOW SWEEPER	A3
1	P099248-2	1	FRAME	
2	P099283-3	1	RIGHT POINT	
3	P099282-3	1	LEFT POINT	
4	P099211-2	1	QUICK COUPLING PLATE	
5	P099307-	2	SUPPORT	
6	P099212-2	1	VERTICAL LEVER	
7	P099232-2	1	GUIDE BAR	[A5]
8	P099246-2	1	REGULATING UNIT, VERTICAL LEVER	[A9]
9	P094985-2	1	REGULATING UNIT, HORIZONTAL LEVER	[A11]
10	P099215-2	1	SUSPENSION	[A13]
11	P099291-1	1	EXTRA PLOW (EXTRA)	[A15]
12	P099291-1	1	EXTRA PLOW (EXTRA)	[A15]
13	4286246	2	CYLINDER	[A17]
14	4286245	2	CYLINDER	[A19]
15	P099259-4	2	GRADER BLADE	
16	P099260-4	2	GRADER BLADE	
17	P094982-2	1	SIGHT	
18	P094983-3	1	SIGHT	
19	P099297-3	2	PIN, UPPER	
20	4276401	16	SPLIT PIN	6,3 X 63 DIN 94-ZNS-ST
21	P099304-3	2	PIN, LOWER	
22	P099288-4	2	BUSHING	
23	P099254-4	2	BUSHING	
24	P099305-3	2	PIN	
25	P099306-3	2	PIN	
26	P095156-4	2	PIN	
27	P095155-4	1	PIN	
28	P099233-4	2	PIN	
29	P099236-4	2	PIN	
30		8	THRUST PLATE	GLACIER WC40DU
31		8	BEARING BUSHING	GLACIER MB 4030DU
32	P099289-4	4	BUSHING	
33	P099235-4	4	BUSHING	
34	4284880	22	LOCK SCREW	M16 X 40 SFS 2458 8.8-ZNS
35	4284496	22	LOCK NUT	
36	0034927	22	WASHER	17 SFS2041-ZNS
37	4272425	8	HEX SCREW	M12 X 70 ISO 4017 8.8-ZNS
38	0035052	8	NUT	M12 SFS2067 M 8-ZNS
39	0010875	8	WASHER	13 SFS2041
40	0012178	15	GREASE FITTING	KR 1/8

12. SPARE PART LIST– VAMMAS

Patria

GUIDE BAR P099232-2

11.11.2005



12. SPARE PART LIST– VAMMAS

Patria

11.11.2005

No	Code	Qty	Name	Description
	P099232-2		*GUIDE BAR	
1	P099122-2	2	BRUSH	[A7]
2	P099220-3	1	BARS	
3		4	HEXAGON HEAD SCREW	M16 X 30 SFS 2064
4		4	NORD LOCK	NL16 SS
5	P099127-3	1	MOUNTING PLATE	

A5

12. SPARE PART LIST– VAMMAS

Patria

11.11.2005


No	Code	Qty	Name	Description
	P099122-2		**BRUSH	
				A7
1	P099129-3	1	LOWER PIPE	
2	P099126-3	1	MOVING FRMAE	
3	P099123-3	1	AXLE	
4	P099130-3	1	FLANGE	
5	P099132-3	1	SPACER PLATE	
6	P099131-3	1	PLASTIC PART	
7		1	HYDRAULIC MOTOR	RG 230 270 320 A18 12
8		1	ROLLER BEARING	22210E, SKF
9		1	SEALING	50X85X10 RST/CC/BASL
10		1	SEALING	58X72X10 RST/CC/BASL
11	P099138-4	5	FASTENER	
12		1	BRUSH UNIT	05013409501350
13		1	BRUSH UNIT	01011025011227
14		1	GREASE NIPPLE	M8
15		25	NORD LOCK	NL12 SS
16		25	ALLEN SCREW	M12 X 30 SFS 2219
17		5	ALLEN SCREW	M12 X 50 DIN 7991
18		5	LOCK NUT	NM12
19		5	NUT	M12 DIN 934
20		7	WASHER	13 DIN 433

12. SPARE PART LIST- VAMMAS

Patria

REGULATING UNIT, VERTICAL LEVER P099246-2

11.11.2005



12. SPARE PART LIST– VAMMAS

Patria

11.11.2005


No	Code	Qty	Name	Description
	P099246-2		*REGULATING UNIT, VERTICAL LEVER	
				A9
1	P099242-3	1	OUTER PIPE	
2	P095133-3	1	INNER PIPE	
3	P095134-3	1	TRAPEZOID THREAD AXLE	
4	P095135-4	1	BUSHING	Ø50/Ø30
5	P095037-3	1	LEVER	Ø12
6	4284677	1	BALL KNOB	P35 M12
7	4284681	1	BEARING BUSHING	MB 3030 DU
9	P095136-4	2	THRUST BEARING	
10	0008407	1	SAFETY RING	30 X 1,5 DIN 471
11	0012178	1	GREASE FITTING	KR 1/8

12. SPARE PART LIST- VAMMAS

Patria

REGULATING UNIT, HORIZONTAL LEVER P094965-2

11.11.2005



12. SPARE PART LIST-VAMMAS

Patria

11.11.2005


No	Code	Qty	Name	Description
	P094965-2		*REGULATING UNIT, HORIZONTAL LEVER	
				A11
1	P095137-3	1	OUTER PIPE	
2	P095133-3	1	INNER PIPE	
3	P095134-3	1	TRAPEZOID THREAD AXLE	
4	P095135-4	1	BUSHING	Ø50/Ø30
5	P095037-3	1	LEVER	Ø12
6	4284677	1	BALL KNOB	P35 M12
7	4284681	1	BEARING BUSHING	MB 3030 DU
9	P095136-4	2	THRUST BEARING	
10	0008407	1	SAFETY RING	30 X 1,5 DIN 471
11	0012178	2	GREASE FITTING	KR 1/8

12. SPARE PART LIST- VAMMAS

Patria

EXTRA PLOW (EXTRA) P099291-1A

11.11.2005



12. SPARE PART LIST– VAMMAS

Patria

11.11.2005

No	Code	Qty	Name	Description
	P099291-1A		*EXTRA PLOW (EXTRA)	
1		1	COVER	
3		1	PIPE	
6		1	PLASTIC PART	
8		1	WASHER	
11		1	PIPE	
13		1	RUBBER PLATE	
14		1	PLATE	
15		1	LOCK NUT	NM30 , 8.8
16		1	COMPRESSION SPRING	D=50, L=250
17		4	HEXAGON HEAD SCREW	M10 X 70 ,8.8
18		4	LOCK NUT	NM10 8.8
19		8	HEXAGON HEAD SCREW	M10 X 35 ,8.8
20		8	WASHER	M10 ZNC


A13

12. SPARE PART LIST- VAMMAS

Patria

CYLINDER 4286246

11.11.2005



12. SPARE PART LIST– VAMMAS

Patria

11.11.2005

No	Code	Qty	Name	Description
	4286246		*CYLINDER	
1	P099359-3	1	CYLINDER PIPE	63/75-266
2	P099360-3	1	PISTON ROD	32-279
3	P099361-4	1	PISTON	63-50
4	P099362-3	1	COVER	M68 X 2
5		1	ROCKER BEARING	GE 30 DO
6		1	LOCK RING	42 X 1,75 DIN 472
7		1	GREASE NIPPLE	R1/8 DIN 71412
8		1	ALLEN SCREW	M8 X 12 DIN 916
	4286275	1	SEALING SET	


A15

12. SPARE PART LIST- VAMMAS

Patria

CYLINDER 4286245

11.11.2005



12. SPARE PART LIST– VAMMAS

Patria

11.11.2005

No	Code	Qty	Name	Description
	4286245		*CYLINDER	
1	P099351-3	1	CYLINDER PIPE	50/50-345
2	P099352-3	1	PISTON ROD	25-349
3	P099353-3	1	COVER	M54 X 2
4	P099354-3	1	PISTON	M20 X 1,5
5		2	ROCKER BEARING	GE 25 DO
6		2	LOCK RING	42 X 1,75 DIN 742
7		2	GREASE NIPPLE	R18 DIN 71412
8		1	ALLEN SCREW	M8 X 12 DIN 916
	4286274	1	SEALING SET	


A17

12. SPARE PART LIST- VAMMAS

Patria

SWEEPER AXLE P099133-2

11.11.2005



12. SPARE PART LIST– VAMMAS

Patria

11.11.2005


No	Code	Qty	Name	Description
	P099133-2		SWEEPER AXLE	
				A19
1	P099129-3	1	LOWER PIPE	
2	P099126-3	1	MOVING FRMAE	
3	P099123-3	1	AXLE	
4	P099130-3	1	FLANGE	
5	P099132-3	1	SPACER PLATE	
6	P099131-3	1	PLASTIC PART	
7		1	HYDRAULIC MOTOR	RG 230 270 320 A18 12
8		1	ROLLER BEARING	22210E, SKF
9		1	SEALING	50 X 65 X 10
10		1	SEALING	58 X 72 X 10
11		1	GREASE NIPPLE	M8
12		1	NORD LOCK	NL10 SS
13		1	NORD LOCK	NL12 SS
14		8	ALLEN SCREW	M12 X 30 SFS 2219
15		5	ALLEN SCREW	M10 X 25 SFS 2219

12. SPARE PART LIST- VAMMAS

Patria

SKID ASSEMBLY P099230-1

11.11.2005



12. SPARE PART LIST– VAMMAS

Patria

11.11.2005

No	Code	Qty	Name	Description
	P099230-1		SKID ASSEMBLY	
1		1	OUTER SUPPORT	
2		1	INNER SUPPORT	
3		1	TRAPEZOID THREAD SHAFT	
4		1	SLEEVE	
5		1	BEARING SLEEVE	
7		2	THRUST BEARING	
8		1	SAFETY RING	
9		1	LEVER	
10		1	KNOB	
11		1	SKID	
12		1	PIN	
13		1	COTTER PIN	
14		1	GREASE NIPPLE	


A21

13. SPARE PART LIST- HAGIE



SNOW PLOW QUICK COUPLER ASSEMBLY

QTY	PART NO.	DESCRIPTION
1	61125	3/4"JIC-3/4"DR ADPTR
2	61127	1 1/16"JIC-1 1/16"DR ADPTR
3	61809	9/16"JIC-3/4"DR ADPTR
4	61803	MULTIFASTER NOBLE




13. SPARE PART LIST- HAGIE



FRONT SPEED VALVE ASSEMBLY

QTY	PART NO	DESCRIPTION
1	606253	CTRL VALVE SOLID PUMP SWAIF
2	611127	1/16NPT-1 1/16NDR APTR
3	618119	9/16NPT-90-9/16NDR LIND
4	618308	1/16NPT-1 5/16NDR APTR
5	618456	9/16FJIC SW RUN TEE-9/16NPT
6	618457	1/16FJ SW RUN TEE-1 1/16NPT
7	900128	3/8UNC X 3/4 HEX BOLT




13. SPARE PART LIST- HAGIE



CONTROL VALVE ASSEMBLY

DET.	QTY	PART NO.	DESCRIPTION	07
1	1	606283	PLD# CTRL VALVE, S&C#R	
2	1	611125	3/4"JIC-3/4"X ADPTR	
3	3	618119	9/16"JIC-9/16"X LHO	
4	6	618126	9/16"JIC-9/16"X ADPTR	
5	1	618327	3/8"JIC-7/8"X ADPTR	
6	4	618629	9/16"X BRANCH TEE-9/16"JIC	
7	2	618634	9/16"JIC-S-9/16"JIC SWIV LHO	
8	1	618637	7/8"X BRANCH TEE-7/8"JIC	
9	2	618734	9/16"JIC .047 DRIFTEE ADPTR	
10	4	900128	3/8"UNC X 3/4" HEX BOLT	




13. SPARE PART LIST– HAGIE



ELECTRIC PANEL ASSEMBLY

DET.	QTY	PART NO.	DESCRIPTION
1	2	290012	DOWN-UP/2 TOWER MIDDLE
2	1	439154	ELECT CTRL MT PANEL, NTB OS
3	1	439155	ELECT CTRL BOX COVER, NTB OS
4	8	470113	5/16UNC HEX FLANGE LOCK NUT
5	4	470118	1/4UNC X 3/4 FLANGE HEX BOLT
6	4	470121	1/4UNC HEX FLANGE LOCK NUT
7	8	470233	5/16UNC X 3/4 FLANGE HEX BOLT




13. SPARE PART LIST- HAGIE



SNOW PLOW LIFTARM ASSEMBLY

QTY	PART NO.	DESCRIPTION
1	2	439006 LWR LIFT ARM W/L 04-MTB STS 03
2	6	439066 LIFT CYL PIN W/L, NTB STS 03
3	2	439070 LIFT CYL MT PIN W/L, NTB STS
4	8	439072 LIFT ARM PIN W/L, NTB STS 03
5	1	439200 BACK LIFT ARM SUPP W/L, ASP 06
6	2	439245 LIFT ARM MT W/L, GST20 06
7	2	470488 HATCHET JACK, 20-28", BALL END
8	2	470499 1" HITCH PIN, W/HANDLE, H3RFPZ
9	16	475015 CUTTER PIN 1/4 X 1 1/2, SS
10	8	618119 9/16X100-90-9/16MBR LRD
11	4	621588 LEVEL CYL, 3.00 X 11.00 STS
12	2	900412 3/4X1/2 X 3" HEX BOLT
13	2	914012 3/4X1/2 HEX STUBER NUT
14	16	920008 1" SHE FLAT WASHER
15	2	439320 W/LMT, INNER PLOW LIFT ARM 07
16	4	121114 SNOW PLOW LIFT RING (PILYGRD)
17	4	629539 RETAINING RING, 3.04 ID SPIRAL
18	4	629622 SEAL, 2.75 X 3.50 X .375 SPECTRA
19	4	439327 W/LMT, OUTER PLOW LIFT ARM 07
20	2	439331 SLTIC STOP, SNOW PLOW LIFT
21	1	165009 RECEPTACLE, MT, STS
22	2	470087 3/8X1/2 HEX FLANGE LOCK NUT
23	2	900128 3/8X1/2 X 3/4 HEX BOLT





PARTS ORDER FAX

**Fax
24 hours
a day
7 days
a week***

Ph. 1 (800) 247-4885 Fx. 1 (515) 532-3553

Photocopy and fax to Hagie Customer Support Department

ORDERED BY/BILL TO:

Name _____
 Co. Name _____
 Street _____
 City, St, Zip _____
 Ph. _____ Fx. _____

SHIP TO:

Name _____
 Co. Name _____
 Street _____
 City, St, Zip _____
 Ph. _____ Fx. _____

HOW SHIP: UPS Ground Next Day Day 3 Day Other _____

If "HOW SHIP" is left blank, parts will be sent UPS ground service. If part is over 150 pounds, an independent motor freight company will be used.

PAYMENT: Hagie Account #** _____

O.D.

American Express Discover Visa MasterCard

Signature: _____

name as appears on card: _____

card no. _____ exp. date _____

Year and Model No. _____

Serial No. _____

Item Serial No. (if necessary):

Engine (include type) _____

Hydrostatic Pump (s) _____

Torque Hub _____ LF RF LR RR

Wheel Motor _____ LF RF LR RR

HAGIE Part No.	Qty.	Description

Check here if you want phone confirmation of parts order.

* Orders received before 3:00 p.m., CST will be processed the same business day.
 Regular business hours are Monday through Friday, 7:00 a.m. through 5:00 p.m..

** If you do not have a Hagie account number, contact the Hagie Customer Support Department and you will be issued one.



PARTS ORDER FAX

**Fax
24 hours
a day
7 days
a week***

Ph. 1 (800) 247-4885 Fx. 1 (515) 532-3553

Photocopy and fax to Hagie Customer Support Department

ORDERED BY/BILL TO:

Name _____
 Co. Name _____
 Street _____
 City, St, Zip _____
 Ph. _____ Fx. _____

SHIP TO:

Name _____
 Co. Name _____
 Street _____
 City, St, Zip _____
 Ph. _____ Fx. _____

HOW SHIP: UPS Ground Next Day Day 3 Day Other _____

If "HOW SHIP" is left blank, parts will be sent UPS ground service. If part is over 150 pounds, an independent motor freight company will be used.

PAYMENT: Hagie Account #** _____

O.D

American Express Discover Visa Master Card

Signature: _____

name as appears on card: _____

card no. _____ exp. date _____

Year and Model No. _____

Serial No. _____

Item Serial No. (if necessary):

Engine (include type) _____

Hydrostatic Pump (s) _____

Torque Hub _____ LF RF LR RR

Wheel Motor _____ LF RF LR RR

HAGIE Part No.	Qty.	Description

Check here if you want phone confirmation of parts order.

* Orders received before 3:00 p.m., CST will be processed the same business day.

Regular business hours are Monday through Friday, 7:00 a.m. through 5:00 p.m..

** If you do not have a Hagie account number, contact the Hagie Customer Support Department and you will be issued one.