

CALIFORNIA

Proposition 65 Warning

WARNING: Diesel engine exhaust and some of its constituents are known to the State of California to cause cancer and birth defects or other reproductive harm.

WARNING: Battery posts, terminals, and related accessories contain lead and lead compounds, chemicals known to the State of California to cause cancer and birth defects or other reproductive harm.



ANY PICTURES CONTAINED WITHIN THIS OPERATOR'S MANUAL THAT DEPICT SITUATIONS WITH SHIELDS, GUARDS, RAILS, OR LIDS REMOVED ARE FOR DEMONSTRATION PURPOSES ONLY. HAGIE MANUFACTURING COMPANY STRONGLY URGES THE OPERATOR TO KEEP ALL SHIELDS AND SAFETY DEVICES IN PLACE AT ALL TIMES.



STS 10



OPERATOR'S MANUAL FOR HAGIE MODEL STS 10 HI-TRACTOR

HAGIE MANUFACTURING COMPANY

BOX 273 CLARION, IOWA 50525

(515) 532-2861

COVERS MACHINE SERIAL NUMBERS:U1610770001 thru U1610770100

12-06 493385

© 2006 Hagie Manufacturing Company. Clarion, Iowa USA

ABBREVIATIONS

| | | | |
|--------------|------------------------------|-------------|------------------------|
| A/C | AIR CONDITIONING | MAINT | MAINTENANCE |
| ACCUM | ACCUMULATOR | MIN | MINUTE |
| ADJ | ADJUST | M/F | MAINFRAME |
| ADPTR | ADAPTER | MPH | MILES PER HOUR |
| ALT | ALTERNATOR | MT | MOUNT |
| AMP | AMPERE | MTH | MONTH |
| APPROX | APPROXIMATELY | MTR | MOTOR |
| ASSY | ASSEMBLY | NO | NUMBER |
| AUX | AUXILIARY | OD | OUTSIDE DIAMETER |
| BRKT | BRACKET | POLY | POLYETHYLENE |
| BTTRY | BATTERY | PRESS | PRESSURE |
| C | CELSIUS | PRKNG | PARKING |
| CAL | CALIBRATION | PSI | POUNDS PER SQUARE INCH |
| CCA | COLD CRANKING AMPS | QT | QUART |
| CHEM | CHEMICAL | RAD | RADIATOR |
| cm | CENTIMETER | REC | RECOMMENDED |
| CYL | CYLINDER | REQ | REQUIRED |
| DIA | DIAGRAM | RPM | REVOLUTIONS PER MINUTE |
| DISPL | DISPLACEMENT | SEC | SECOND |
| EA | EACH | SERV | SERVICE |
| ELECT | ELECTRIC | SMV | SLOW MOVING VEHICLE |
| F | FAHRENHEIT | SOLE | SOLENOID |
| FIG | FIGURE | SOLU | SOLUTION |
| FRT | FRONT | SPEC | SPECIFICATION |
| FT | FOOT OR FEET | STRG | STEERING |
| GA | GAUGE | SQ | SQUARE |
| GAL | GALLON | TACH | TACHOMETER |
| GPA | GALLONS PER ACRE | TEMP | TEMPERATURE |
| GPM | GALLONS PER MINUTE | TERM | TERMINAL |
| GPS | GLOBAL POSITIONING SATELLITE | TRD | TREAD |
| HAL | HALOGEN | TT | TUBE-TYPE |
| HR | HOOR | TU | TUBELESS |
| HYD | HYDRAULIC | VAR | VARIABLE |
| HYDRO | HYDROSTATIC | V | VOLT |
| ID | INSIDE DIAMETER | VFC | VARIABLE FLOW CONTROL |
| IN | INCH | VLV | VALVE |
| INFO | INFORMATION | W/ | WITH |
| Km/H | KILOMETERS PER HOUR | W/O | WITHOUT |
| L | LITER (DISPLACEMENT) | W | WEIGHT |
| l | LITER (LIQUID) | WD | WHEEL DRIVE |
| LB | POUND | WHL | WHEEL |
| m | METER | WK | WEEK |

TO THE OWNER



A WORD FROM HAGIE MANUFACTURING COMPANY

Congratulations on your selection of a Hagie Model STS 10 sprayer. We recommend that you study this Operator's Manual and become acquainted with the adjustments and operating procedures before attempting to operate your new sprayer. As with any piece of equipment, certain operating procedures, service, and maintenance are required to keep it in top running condition.

We have attempted herein to cover all of the adjustments required to fit varying conditions. However, there may be times when special care must be considered.

Hagie Manufacturing Company reserves the right to make changes in the design and material of any subsequent sprayer without obligation to existing units.

We thank you for choosing a Hagie sprayer and assure you of our continued interest in its satisfactory operation for you. If we might be of assistance to you, please call us.

We are proud to have you as a customer.

CAUTION

READ OPERATOR'S MANUAL. BE ALERT. LEARN TO OPERATE THIS MACHINE SAFELY. OBSERVE ALL SAFETY PRACTICES. MACHINES CAN BE HAZARDOUS IN THE HANDS OF AN UNFAMILIAR, UNTRAINED, OR COMPLACENT OPERATOR. SHUT OFF ENGINE BEFORE SERVICING. WHEN MECHANISM BECOMES CLOGGED, SHUT OFF ENGINE BEFORE CLEANING. DON'T RISK INJURY OR DEATH.

TO THE OPERATOR

The following pages and illustrations will help you operate and service your new sprayer. It is the responsibility of the user to read the Operator's Manual and comply with the safe correct operating procedures and lubricate and maintain the product according to the maintenance schedule.

The user is responsible for inspecting the machine and having parts repaired or replaced when continued use of the product causes damage

or excessive wear to other parts.

Keep this manual in a convenient place for easy reference when problems arise. This manual is considered a permanent fixture with this machine. In the event of resale, this manual should accompany the sprayer. If you do not understand any part of the manual or require additional information or service, contact the Hagie Customer Support Department:

Hagie Manufacturing Company
Box 273, Clarion, IA 50525
(515) 532-2861

The following symbols, found throughout this manual, alert you to potentially dangerous conditions to the operator, service personnel, or the equipment.



This symbol indicates a hazardous situation which, if not avoided, will result in death or serious injury.



This symbol indicates a potentially hazardous situation which, if not avoided, could result in death or injury.



This symbol indicates a potentially hazardous situation which, if not avoided, may result in minor or moderate injury. It may also be used to alert against unsafe practices.

TABLE OF CONTENTS

| | | |
|-------|------------------------------|-------|
| I. | SAFETY/DECALS..... | 4-12 |
| II. | SPRAYER IDENTIFICATION..... | 13-14 |
| III. | SPECIFICATIONS..... | 15-19 |
| IV. | OPERATING INFORMATION..... | 20-53 |
| V. | CALIBRATION..... | 54-55 |
| VI. | TRANSPORTING..... | 56-57 |
| VII. | SERVICE AND MAINTENANCE..... | 58-81 |
| VIII. | STORAGE..... | 82-83 |
| IX. | TROUBLE SHOOTING..... | 84-92 |
| X. | LIMITED WARRANTY..... | 93 |
| XI. | INDEX..... | 94-95 |

I. SAFETY/DECALS

SAFETY PRECAUTIONS

Most accidents occur as the result of failure to follow simple and fundamental safety rules. For this reason, most accidents can be prevented by recognizing the real cause and doing something about it before the accident occurs.

Many conditions cannot be completely safeguarded against without interfering with efficient operation and/or reasonable accessibility. Therefore, you must study this Operator's Manual

and learn how to use the sprayer controls for safe operation. Likewise, do not let anyone operate without instruction.

Do not make modifications such as weldments, add-ons, adaptations, or changes from the original design of sprayer. Such changes and/or modifications may become safety hazards to you and to others and will void all warranties.

DRIVING

- Before moving sprayer, make sure no persons or obstructions are in path of travel.
- Do not permit passengers on sprayer when it is moving; they may fall off or obstruct operator's view.
- Never drive near ditches, embankments, holes, mounds, or other obstacles.
- Never drive on hills too steep for safe operation.
- Always drive at a reasonable field speed.
- Reduce sprayer's speed before turning.
- Come to a complete stop before reversing direction.
- Pull over to side of road before stopping.
- Additional weight caused from partially full or full solution tanks may cause erratic or increased stopping distance.
- Never operate sprayer on roadway with any solution in solution tank.
- Do not activate parking brake while machine is in motion or damage may occur to sprayer.
- Use flashing/hazard warning lights when traveling on public roads, day or night, unless prohibited by local law.
- Make sure SMV and SIS emblem is in place and visible from rear when traveling on public roads.

I. SAFETY/DECALS



TREAD WIDTH

- Select widest tread setting to fit between crop rows.

SPRAYER BOOMS

- Cradle booms when leaving sprayer unattended.
- Make sure booms are folded when cradled.
- Select a safe area before unfolding booms. Avoid power lines and overhead structures.

GENERAL OPERATION SAFETY

- Do not adjust factory engine RPM settings.
- Operate engine at one bump to assure proper charge pressure for brakes to work properly.
- Start engine from operator's seat only. Do not by-pass safety-start switch.
- Never use starting fluid to assist engine start up.
- Never run sprayer engine in a closed building. Proper exhaust ventilation is required.
- If equipped with ground speed sensing radar, do not look directly into radar beam. It emits a very low intensity microwave signal which may cause possible eye damage.

I. SAFETY/DECALS

REPAIR/MAINTENANCE

HYDRAULICS

- Use caution when working with hydraulic fluid under pressure. Escaping hydraulic fluid can have sufficient force to penetrate your skin, causing serious injury. This fluid may also be hot enough to burn.
- Always lower load or relieve hydraulic pressure before repairing a hydraulic oil leak.
- Avoid torching, welding, and soldering near pressurized hydraulic lines.

FUELING

- Always turn engine off and allow it to cool before refueling.
- Do not smoke while refueling.
- Do not fill fuel tank completely. Fuel may expand and run over.

GENERAL REPAIR/MAINTENANCE

- Turn off engine before checking, adjusting, repairing, lubricating, or cleaning any part of sprayer.
- When servicing radiator, let engine cool before removing pressurized cap.
- Disconnect battery ground cable and turn main battery switch off before servicing electrical system or welding on machine.
- When charging battery, connect positive cable to positive terminal and negative cable to negative terminal. Failure to do so may result in an explosion and cause injury. Likewise, avoid battery acid contact with body.

I. SAFETY/DECALS



CHEMICAL HANDLING

- Never allow chemicals to come in contact with skin or eyes. Wear protective clothing or respirators as recommended by chemical manufacturer. Store this clothing outside cab so as not contaminate filtered cab environment. Also, clean your boots to remove soil or other contaminated particles prior to entering cab.
- Never pour chemicals into an empty tank, fill tank half full of water first.
- Follow chemical manufacturer's instructions for mixing chemicals.
- Dispose of empty chemical containers properly.
- Wash spilled chemicals or spray residue from sprayer to prevent corrosion and deterioration.
- Select a safe area to fill, flush, calibrate, and clean sprayer where chemicals will not drift or run off to contaminate people, animals, vegetation, or water supply.
- Never place nozzle tips or other parts to one's lips in an attempt to unclog spray tip.
- Do not spray when wind is in excess of chemical manufacturer's recommended speed.
- Store pesticides in their original containers with label intact. Keep them in a separate, locked building.



GENERAL SAFETY

- Keep a fire extinguisher close at all times.
- Keep all shields in place.
- Keep clear of all moving parts and keep others away when operating.
- Do not wear loose fitting clothing that may be blown or drawn into moving parts.

WARNING DECALS 

I. SAFETY/DECALS

WARNING DECALS

Decals warning you of avoidable danger are located on various parts of the sprayer. They are there for your personal safety and protection. DO NOT remove them. They will fracture upon attempted removal and therefore must be replaced.

Following are locations of important safety decals. Replace them if they are torn or missing. All

warning decals and other instructional Hagie decals or machine striping may be purchased through the Hagie Customer Support Department. To replace decals, be sure that the installation area is clean and dry; decide on exact position before you remove the backing paper.

DECAL LOCATION



650107



Rear of mainframe above booster terminals.



650165

Right side cab post.



I. SAFETY/DECALS



650118

On engine compartment, in front of air intake.



650165

Inside right-hand cab post by rear window.



650339

On hydraulic reservoir, to left of sight gauge.



DECALS CONTINUED

I. SAFETY/DECALS



650339

On front cross member, left side.



650340

On console above switches.




650848

On ladder pivot tube.




I. SAFETY/DECALS



650849

On engine compartment, near fuel cell cap.



650850

On solution tank, near fill lid.



650851

Left rear mainframe.



DECALS CONTINUED 

I. SAFETY/DECALS




650852

Right side cab post.



650981

In engine compartment, near radiator cap.



650982

Above top battery.



II. IDENTIFICATION NUMBERS



SPRAYER IDENTIFICATION

Each Hagie sprayer is identified by means of a frame serial number. This serial number denotes the model, year in which it was built, and the number of the sprayer. For further identification, the engine has a serial number, the hydrostatic pumps have serial numbers, the wheel motors have identification tags, and the planetary hubs have

identification plates that describe the type of mount and gear ratio. To ensure prompt, efficient service when ordering parts or requesting service repairs from Hagie Manufacturing Company, record the serial and identification numbers in the space provided below.

NOTE:

Reference to left-hand and right-hand used throughout this manual refers to the position when seated in the operator's seat facing forward.




Sprayer

NOTE: Sprayer serial number stamped in the frame on right rear corner and metal tag on frame by ladder.

Engine

NOTE: Diesel engine serial number located on gear housing under A/C compressor.

II. IDENTIFICATION NUMBERS




Planetary Hubs

Left

Right

Front: _____


Rear: _____



Hydrostatic Pumps

Front: _____

Rear: _____




Front Wheel Motors

Left: _____

Right: _____

Refer to parts manual.



Rear Wheel Motors

Left - w/
Sensor: _____


Right - w/
Sensor: _____

Refer to parts manual.

III. SPECIFICATIONS


SPRAYER DIMENSIONS

- | | | | |
|----------------------------------|---------------------|---|--------|
| A. Overall tractor height | 149" | E. Wheel base | 140" |
| B. Raised transom height..... | 142.5" | F. Sprayer length to engine rear..... | 311.5" |
| C. Transom lift range..... | 20-105" (85" range) | G. Sprayer length to booms folded | 318" |
| D. Static loaded hub height..... | 33.5" | | |



- | | |
|---|---------------------------|
| H. Width (booms folded, 120" tread)..... | 143" |
| I. Frame clearance | 72" |
| J. Lower leg clearance | 27" (rear) |
| K. Tire center to inside of lower leg | 13.5" (rear) |
| L. Tread width* | Adjustable 120" - 152" |

*NOTE: Measure tread width at 1/2 tire height.



GENERAL SPRAYER INFORMATION

- | | | | |
|--------------------|--------------------------------|-------------------------------|------------|
| ◆ Frame type | 4 x 8 " modular platform frame | ◆ Approximate dry weight..... | 18,630 lb. |
| ◆ Suspension | 4-wheel, ind., auto air-ride | ◆ Shipping width | 143" |

III. SPECIFICATIONS

ENGINE

| | |
|--|--|
| Manufacturer and model | Cummins |
| Model | QSB5.9-220 |
| Type | Electronic with air to air cooler and turbocharger |
| Number of cylinders | 6 |
| Displacement | 5.9 liter (360 c.i.) |
| Power | 215 hp (205 kW), (power bulge to 225hp) |
| Type of fuel | Number 1 or number 2 diesel |
| Fuel system | Filtered, direct-injected |
| Air cleaner | Dry-type, single element |
| Engine air filter restriction monitor..... | Filter Minder® |
| Slow idle..... | 800 RPM |
| Fast idle..... | 2500 RPM (no load) |

POWER TRAIN

Drive

| | |
|--|--|
| Hydrostatic pump | Sauer-Danfoss Tandem 90 series |
| Range..... | 150cc (75 X 2) pressure compensated with electronic displacement control |
| Drive train..... | All-time four wheel drive |
| Speed - Low | 0-14 mph (0-22.5 km/h) |
| - Medium | 0-18 mph (0-29.0 km/h) |
| - High | 0-30 mph (0-48.5 km/h) |
| Hydrostatic wheel motors- front and rear | Sauer-Danfoss (90 series) |
| Final drives | |
| Type | Planetary gear reduction hubs |
| - front and rear | Torque Hub® CW12 |
| Lubrication | Oil bath |

Brakes

| | |
|------------|---|
| Type | Multiple disc Spring applied Hydraulically released |
|------------|---|

Steering System

| | |
|--|-------------------------------|
| Type | Hydraulic, dedicated circuit |
| Control..... | Full-time power |
| Steering cylinders..... | Self-centering, double action |
| Turning radius (120" tread setting)..... | 18 ft. (5.5 m) |

III. SPECIFICATIONS

AUXILIARY HYDRAULIC SYSTEM

Type Load sense
Pump type Single closed center pump

SPRAY SYSTEM

Booms

Type Dry, with variable row spacing(optional wet)
Standard 60/80/90/100 ft. (5 spray sections)
Controls Electro-hydraulic: fold/lift/level
Level shock absorber Gas-charged accumulator
Outer boom tip hydraulic breakaway Self-actuated, auto-reset hydraulic

Solution Fill Connection

Quick-fill connection 3 in. (7.6 cm) I.D.

Solution Tank

Standard 1000 gal. (3785 ℓ) polyethylene w/sight gauge
Optional 1000 gal. (3785 ℓ) stainless steel w/sight gauge
Agitation (polyethylene tank) Eductor-type w/elect. var. speed control
Agitation (stainless steel tank) Sparge-type w/elect. var. speed control

General Spray System

Pump Centrifugal - hydraulically driven with pulse width modulated control valve
Solution valves Electric ball valves
Pressure gauge 100 PSI glycerin filled
Monitor Raven 4600 (GPS-ready)
Fence row nozzle Two position, remote activated

FOAM MARKING SYSTEM

Make Hagie Foam Marker
Type Live air

RINSE SYSTEMS

Spray system rinse (solution tanks, pump, and booms) Standard
High pressure washing system Optional

III. SPECIFICATIONS

ELECTRICAL SYSTEM

General Electrical System

| | |
|-----------------|----------------------------|
| Battery..... | Dual 12V, negative ground |
| Alternator..... | 130 AMP, voltage regulated |
| Starter | 12V with solenoid |

Circuit Breakers/Fuses (See Model STS 10 Parts Manual.)

Lights

| | |
|------------------------------|--|
| Front of cab | 2 Trapezoidal head lights and 4 flood lights |
| Transom mount..... | 2 Trapezoidal head lights |
| Boom cradle (forward)..... | 2 Trapezoidal flood lights (1 each) |
| Boom cradle (rearward) | 2 Trapezoidal flood lights (1 each) |

CAB AND INSTRUMENTS

Cab

| | |
|----------------------------|--|
| General cab..... | Tilt steering Windshield wiper/washer Dual side mirrors Dome light Tinted glass Training seat |
| Temperature control..... | Full-range |
| A/C charge type | R-134a |
| Fresh air filtration | Paper and charcoal filter |
| Seat..... | Air ride |

Instruments

| | |
|---------------------|--|
| Message center..... | Hour meter Fuel Water temperature Battery voltage Engine oil pressure Ground speed Engine RPM Tread adjustment assist |
|---------------------|--|

| | |
|-------------|------------------|
| Stereo..... | AM/FM/WB with CD |
|-------------|------------------|

III. SPECIFICATIONS

TIRES

Tires (front and rear)

| | |
|--|--------------------------------------|
| Standard..... | 380/90R46 (Radial TU) |
| Air pressure | 35 PSI (240 kpa) |
| Tire width | 15.0 in. (381 mm) |
| Load capacity at 25 MPH (40.2 Km/H)..... | 7150 lbs. (3250 kg) |
| Overall diameter | 72.7 in. (1847 mm) |
| Static load radius (suggested—will vary with load) | 33.5 in. (851 mm) |
| Rolling circumference..... | 219.0 in. (5563 mm) |
| Optional (narrow row crop)..... | 380/90R54 (Radial TU) (Titan 320-90) |
| Air pressure | 35 PSI (517 kpa) |
| Tire width | 12.6 in. (381 mm) |
| Load capacity at 30 MPH (40.2 Km/H)..... | 6800 lbs. (5987.5 kg) |
| Overall diameter | 72.6 in. (2042.2 mm) |
| Static load radius (suggested—will vary with load) | 33.8 in. (947.42 mm) |
| Rolling circumference..... | 219.0 in. (6147 mm) |
| Optional (wide)..... | 580/70R38 (Radial TU) |
| Air pressure | 23 PSI (160 kpa) |
| Tire width..... | 23.1 in. (587 mm) |
| Load capacity at 25 MPH (40.2 Km/H)..... | 8550 lbs. (3875 kg) |
| Overall diameter | 72.2 in. (1834 mm) |
| Static load radius (suggested—will vary with load) | 32.4 in. (823 mm) |
| Rolling circumference..... | 216.4 in. (5497 mm) |

CAPACITIES

| | |
|---|-------------------------------|
| Solution tank | 1000 gallons (3785 ℓ) |
| Fuel cell..... | 150 gallons (530 ℓ) |
| Cooling system (including block, lines & radiator)..... | 18 gallons (68 ℓ) |
| Hydraulic oil (including tank, lines, filter & cooler)..... | 55 gallons (208 ℓ) |
| Rinse system tank..... | 100 gallons (379 ℓ) |
| Foam marker tank..... | 36 gallons (136 ℓ) |
| Engine oil (including crankcase, lines, filter & cooler)..... | 17 quarts (16 ℓ) |
| Torque Hub® | |
| Front (2)..... | 84 oz. (2.5 ℓ) each (approx.) |
| Rear (2) | 62 oz. (1.8 ℓ) each (approx.) |

IV. OPERATING INFORMATION

OPERATING THE ENGINE

| Pre-operational Checks | Page Reference |
|--|----------------|
| 1. Check the engine oil level. Do not operate the engine when oil is below the low mark on dipstick. | 62 |
| 2. Check the coolant level in the radiator and the coolant overflow reservoir. | 64-65 |
| 3. Check the hydraulic oil reservoir level. | 62 |
| 4. Check cooling air intake screen. | 68 |
| 5. Check engine drive belt. | 74 |
| 6. Drain fuel/water separator. | 70 |
| 7. Check the Filter Minder®. | 67 |
| 8. Check for any oil or fuel leaks and correct if needed. | |
| 9. Drain any water out of air tank daily. | 79 |

Starting the Engine



IV. OPERATING INFORMATION



FIG 4.01



FIG 4.02

CAUTION

Start engine from operator's seat only.
When running engine in a building, be sure there is adequate ventilation.

1. Position hydrostatic control lever to "N" (neutral) position.
2. Put the parking brake switch (fig. 4.01) to the "ON" position. (See page 24) . Turn the ignition key switch to the on position, wait for the wait to start light in the message center to go out (fig.4.02), then engage the starter. If the engine fails to start after 15 seconds, turn key to "OFF", wait one minute and repeat the procedure. If the engine does not start after three attempts, check fuel supply system. Absence of blue or white exhaust smoke during cranking indicates no fuel is being delivered.
3. Observe warning lights on message center (fig. 4.02) after start up.
4. If any functions do not operate, shut off engine and determine cause.
5. Always allow at least a five minute warm-up period before operating the engine at high RPM. This means the engine must reach operating temperature and oil pressure must stabilize in the normal operating range before it is run faster than an idle (1000 RPM or less).

NOTE:

Cold oil may not flow in quantities adequate to prevent pump cavitation.

IV. OPERATING INFORMATION



FIG 4.03



FIG 4.04



FIG 4.05

Operating Ladder

CAUTION

DO NOT lower ladder while anyone is on ground near sprayer. DO NOT attempt to lower ladder from ground level. Ladder may swing down quickly and strike others or operator.

To raise or lower the hydraulic ladder, locate the Park/Brake switch on the right-hand console (fig.4.05). By applying the Park Brake/Ladder switch, the ladder will lower automatically (fig.4.03), when engine is shut off. If the Park Brake/Ladder switch is pushed, the ladder will automatically raise when machine is running (fig.4.04).

CAUTION

Upright ladder is not service platform or step. DO NOT step on ladder while in upright position.

IV. OPERATING INFORMATION

HYDROSTATIC SYSTEM



FIG 4.06



FIG 4.07




FIG 4.08

NOTE:

Machine will not shift down until highest speed of desired range is met.

ACE: Automatically Controlled Engine Hydrostatic Drive

1. Speed ranges are selected by a red and green electronic switch mounted on the hydrostat handle (fig. 4.06,). The lower the setting, the higher the torque, but the lower the speed.
2. Increase engine one bump to gain RPM of 1800 with the throttle switch (fig. 4.07, item 2) ore RPM will be gained as you move the hydrostatic handle forward.
3. To move forward, slowly push the hydrostatic control lever (fig. 4.07, item 1) forward. The farther the control lever is moved, the faster the sprayer will travel and the RPM's will increase. To stop, slowly pull the lever to the "N" (neutral) position.
4. To reverse the machine, slowly pull the hydrostatic control lever back. To stop, slowly push the lever to the "N" (neutral) position.
5. Before turning off the engine, reduce engine speed and allow the engine to idle at least three minutes.

Cruise Control

Cruise control may be adjusted with the cruise control dial (fig. 4.08). This will conveniently help regain consistent field speeds when reentering a field from the end rows.

To set a cruise limit, start with the engine at one bump on the throttle switch or 1800 RPM's and cruise control dial all the way (counterclockwise). Push the hydrostatic control lever all the way forward. Now turn the cruise control dial clockwise while observing the ground speed and stop turning the dial when the desired field speed is reached. Now your maximum field speed is set and you simply reposition the handle all the way forward to regain that speed.

IV. OPERATING INFORMATION



FIG 4.08



FIG 4.09

Parking Brake

When the engine is shut off or if the charge pressure is below 150 PSI the brakes will become activated. To set the brakes while the engine is running, activate the switch located on the right-hand switch panel.

To engage the brakes, depress the top of the switch (fig. 4.08) in. To release the brakes, depress the bottom of the switch in (4.09). Always return the brake switch to the "OFF" position before moving the sprayer. Brake switch must be on to lower the ladder, and also to run the side fill or power washer. When brake is on the ladder will lower automatically.

NOTE:

The parking brake will not engage over 1 mile per hour.

IV. OPERATING INFORMATION

HYDRAULIC SYSTEM

The auxiliary hydraulic system is an open type directly mounted behind the heavy duty variable displacement pump and right side of engine. The systems consists of single variable displacement pump that supplies the required hydraulics to operate the full time power steering unit, boom

control cylinders (lift, level and fold), tread adjust, ladder if equipped, outer boom breakaway and the solution pump.

After supplying each of these systems, the hydraulic oil is sent to the oil cooler at the rear of the engine compartment. Here it is cooled and then sent back to the hydraulic oil reservoir.



FIG 4.11

NOTE:

The red warning light (fig.4.11) will illuminate if the oil level in the hydraulic reservoir drops too low to safely operate the machine. If this occurs, you must shut down the engine immediately to prevent damage to hydraulic system.

NOTE:

The red warning light will illuminate when any fault is detected. An explanation of the fault will appear on the message center.

CAUTION

DO NOT GO NEAR LEAKS. High pressure oil easily punctures skin causing injury, gangrene, or death. If injured, seek emergency medical help. Immediate surgery is required to remove oil. Do not use finger or skin to check for leaks. Lower load or relieve hydraulic pressure before loosening fittings.

IV. OPERATING INFORMATION



FIG 4.12



FIG 4.13




FIG 4.14

Operating the Hydraulic Tread Adjust

CAUTION

Never adjust the hydraulic tread on a public roadway. Make sure the sprayer is on level ground where there are no ditches or valleys to interfere when you perform the adjustment.

1. Survey the surroundings and allow yourself enough room to adjust tread either in forward or reverse.
2. Locate the tread adjustment switches on right-hand console (fig. 4.12). They are marked LF (left front), LR (left rear), RF (right front) and RR (right rear). The legs may be moved in or out on each side independently. While driving between one and two mph, press and hold the desired switches to move tread in the desired direction. Pressing the top of any switch will move that leg OUT and pressing the bottom of any switch will move that leg IN.
4. Observe the tread width on each leg. Front legs use indicator decals (fig. 4.13) and rear legs use electronic sensors and the message center in the cab (fig. 4.14). See page 53 for information about message center. Release the switch when the tread indicator reaches the desired tread marking.
5. After adjustment is complete, all four tread width indicators should have identical readings.
6. To recalibrate toe-in: while driving forward slowly, turn the steering wheel all the way one way until the steering cylinder bottoms out; continue turning the wheel a little more to let fluid bypass the cylinder. Then turn the steering wheel all the other way and repeat the process. When wheels are then straightened, steering cylinders should be recentered and correct toe-in should be obtained (see page 76).

IV. OPERATING INFORMATION



FIG 4.15



FIG 4.16




FIG 4.17

Adjusting Tread Width Manually

1. Empty solution from tank, turn off engine and set parking brake on level surface.
2. Chock all three wheels, front and back, that are not being adjusted.
3. Lock suspension up on the leg being adjusted with a solid block between points 1 and 2 (fig. 4.15).
4. After lifting with properly-rated overhead hoist or floor jack, position properly-rated jack stand under frame and lower sprayer onto stand (fig. 4.16). Remove floor jack if used. Tire of leg being adjusted should be approximately six inches off ground.
5. Loosen all eight tread adjust tension bolts on the leg to be adjusted (fig. 4.17) one turn each. Tension bolts should only be loosened, NOT removed. Do NOT remove or loosen any of the other three legs' tension bolts at this time.

CAUTION

Adjust the tread setting of only one leg at a time.

6. Slowly slide leg assembly to desired width. Use of a hand cable winch or other pulling tools may be required.
7. Retighten tread adjust tension bolts to 100 lb-ft of torque. See page 76 for additional tread adjust tension bolt information.
8. Lower leg and repeat previous steps until all four axles have desired tread width.

IV. OPERATING INFORMATION


SPRAY BOOMS

Hydraulically folding the extensions of the 60/80/90 foot boom system and adjusting spray valves essentially turns it into a 60 foot boom (see pages 32 & 37). Manually folding the outer extensions of the 60/80/90 foot system, adjusting spray valves and recalibrating spray monitor essentially turns it into an 80 foot boom (see pages 34 & 54).

The spray booms are controlled by an electro-hydraulic system. This system consists of operator manipulated switches located in the sprayer's cab and hydraulic cylinders attached to the booms. It provides

control of lift (page 29), level (page 30), horizontal fold (page 31) and vertical fold (page 32).

All STS 10 spray booms are equipped with a hydraulic breakaway circuit. When folded out as an 80 or 90 foot spray boom, a one-way hydraulic circuit on the outer boom section provides outer boom breakaway functions. The outer breakaway is self-resetting and will return to normal operating position after it has cleared the hazard.



IV. OPERATING INFORMATION



FIG 4.18

Lift

To raise and lower the transom/boom assembly, depress the “Square Rocker” (UP) or the “Square Rocker” (DOWN) on the hydrostatic drive handle (fig. 4.19 item 1). While depressed, either button activates the transom lift cylinders (fig. 4.18).



FIG 4.19

NOTE:

See your spray tip manufacturer's guide for information regarding spray tip height (fig. 4.20).




FIG 4.20

IV. OPERATING INFORMATION



FIG 4.21

Level

To increase or decrease the angle of each individual boom level, depress the left or right “Round Rocker” (UP) or the left or right “Round Rocker” (DOWN) buttons on the hydrostatic drive handle (fig. 4.22, items 1 and 2). While depressed, these buttons activate the level cylinders connecting either boom to the transom (fig. 4.21).

This adjustment also aids in placing the booms correctly in the cradles for transporting and storing.




FIG 4.22




FIG 4.23

IV. OPERATING INFORMATION



FIG 4.24

Fold

HORIZONTAL BOOM FOLD - To fold either boom horizontally in toward the machine or out, depress the right or left Rocker "Boom Fold" switches on the hydrostat handle (fig. 4.25). While depressed, these switches activate cylinders connecting either boom to the transom (fig. 4.24).

Fold or unfold the booms in an open area only. Make sure no one is standing in the path of the boom fold's travel path. Booms can be folded if speed is less than (5MPH).



FIG 4.25




FIG 4.26

IV. OPERATING INFORMATION



FIG 4.27

Fold


VERTICAL EXTENSION FOLD - To fold the boom extensions vertically in or out, depress the top or bottom of the “Boom Extension” switch (fig. 4.28). This activates both extension cylinders connecting the inner boom section and the center boom section (fig. 4.27).

Fold or unfold the booms in an open area only. Make sure there are no overhead obstructions or wires to interfere with extension folding.

NOTE:

Booms extensions can only be folded when hydrostatic control lever is in the neutral position, and you have pushed the (F1) or ok in the message center showing you have acknowledged there are no power lines overhead. If sprayer is put in gear during folding, booms will stop.

⚠ DANGER



CONTACT WITH OVERHEAD ELECTRICAL WIRES AND DEVICES WILL CAUSE SEVERE INJURY OR DEATH. AVOID CONTACT-FOLD BOOMS IN AN OPEN AREA ONLY.



FIG 4.28




FIG 4.29

IV. OPERATING INFORMATION



FIG 4.30



FIG 4.31

Cradling Booms

The booms should always be cradled before traveling, transporting, or parking for an extended period of time. The booms must be folded when cradled. To cradle the booms, fold the boom extensions in, raise the transom, and fold the booms in toward the machine. When the boom reaches the last 8-10 degrees of travel towards the cradle, it will automatically slow down to avoid impact with cradle. Raise each individual boom level until it clears the outer cradle stop (fig. 4.30). Fold the boom in toward the cradle back-stop. When it touches the back-stop, lower the boom level until the full weight of the boom rests in the cradle (fig. 4.31).

NOTE:

Booms must be in folded position when cradled. Failure to do so may cause boom damage.




FIG 4.32

IV. OPERATING INFORMATION



FIG 4.33

Folding 90' Boom to 80' Boom

To convert a 90 foot boom to an 80 foot boom, manually close the solution supply valve on the outer section (fig. 4.33). Remove the pin on the back side of the boom so it will hinge forward (fig. 4.34) and secure it with rear pin (fig. 4.35) Repeat these steps on the other side and recalibrate monitor accordingly (see page 54) before spraying resumes. See page 43 for information regarding foam marker width adjustment.



FIG 4.34



FIG 4.35

IV. OPERATING INFORMATION

SPRAY SYSTEM

The spraying system is a constantly-monitored information from various inputs to help determine and continuously-adjusted computer-controlled GPM (gallons per minute) and GPA (gallons per system. The cab-mounted digital monitor receives acre).

SPRAY SYSTEM OPERATION INSTRUCTIONS

| OPERATION | PAGE REFERENCE |
|---|--------------------|
| 1. Calibrate spraying system monitor. | 54 |
| 2. Check contents and quantity in spray tank. | |
| NOTE: Never attempt to operate the spray system without solution in the spray tank. Operating the spray system with no solution in the tank will cause severe damage and void the warranty. | |
| 3. Start engine. | 20 |
| 4. Open tank valves, if desired, activate the agitation system. | 37,42 |
| 5. Turn on the work mode switch. | 36 |
| 6. Turn on main spray power. | 38 |
| 7. Place individual boom solution valve switches to the “ON” position. | 38 37 |
| 8. Slowly move the hydrostatic control lever forward to obtain the desired ground speed. | 23 |
| 9. Frequently observe the pressure gauge. When it drops to zero, or spray pattern deteriorates, shut off main spray power, solution pump, and agitation system until refilling solution. | 36, 38, 36, 42, 40 |

IV. OPERATING INFORMATION



FIG 4.36

Solution Pump

The solution pump (fig.4.36), is controlled by the Raven monitor and the Controlled Pulse Modulated Valve (fig.4.37A&B).

Solution Pressure Gauge

The solution pressure gauge (fig. 4.38) gives the operator a constant visual display of the amount of solution being applied (measured in PSI). The pressure (as determined by the Pulse width Modulated control valve) will vary according to ground speed. If applying solution manually, the solution pressure gauge visually informs the operator of needed manual adjustments. Gauge also shows when there is a drop in pressure the solution tanks may be empty or a problem with the system.



FIG 4.37A&B

NOTE:

DO NOT allow the pump to continue running when the boom switches are turned off (see page 37). Failure to do so will generate over-heating and cause severe pump damage and void the warranty.



FIG 4.38

IV. OPERATING INFORMATION

Boom Solution Valve Switches



FIG 4.39A

The spray booms are divided into sections that are independently supplied with solution and can therefore independently be shut off or turned on. Sixty foot boom configurations are divided into three sections and the valves are mounted on the transom. Eighty and ninety foot boom configurations are divided into five sections with three valves mounted on the transom and one mounted on each boom. The electronic boom solution valves are controlled by a row of switches mounted on the right-hand console (fig.4.39A).

Solution Tank Valve



FIG 4.39B

The solution tank valve switch is also located on the right hand console (fig 4.39B). Fig 4.39C shows the location of the tank valve.

Boom Section L.E.D. Indicators

Boom solution valve status is displayed on the transom by a series of L.E.D. indicators (fig. 4.40). Each indicator will light up if that particular boom solution valve is turned “OFF.”



FIG 4.39C



FIG 4.40

IV. OPERATING INFORMATION



FIG 4.42

Main Solution Switch

Main spray power can be controlled from a switch mounted on the hydrostatic control lever (fig. 4.42). This controls the panel of boom solution valve switches . The switch must be on to supply the switches with voltage. This way you can turn all of the boom solution valves “ON” or “OFF” all at once in a hands-free execution such as turning the main solution switch “OFF” as you arrive at the end rows of a field and turn it back “ON” as you enter the field again. This switch supplies the power to the boom solution valve switches that you turn off to disconnect the power.



FIG 4.43A

When the main spray power is “ON” a “GREEN” indicator light mounted on the right side of the message center will light up (fig. 4.43A), also a white light mounted above boom lights on transom assembly (fig.4.43B), will come on. When the light is not lit, the main solution switch is “OFF.”



FIG 4.43B

IV. OPERATING INFORMATION




FIG 4.44

Fence Row Applicator

To operate the fence row nozzle, locate the fence row switch on the switch control panel (fig. 4.44). If you wish to turn on the right fence row nozzle, depress the top side of the fence row switch. If you wish to turn on the left fence row nozzle, depress the bottom side of the fence row switch. To turn either fence row nozzle off, return the fence row switch back to the center (“OFF”) position.

As you engage either fence row nozzle you may notice a drop in solution pressure.

A set of amber L.E.D. lights mounted on the transom on either side of the boom solution valve L.E.D. lights will inform the operator of fence row status. If the left fence row nozzle is on, the left amber L.E.D. light is lit (fig. 4.45, item 1). If the right fence row nozzle is on, the right amber L.E.D. light is lit (fig. 4.45, item 2). If neither amber L.E.D. light is lit, no solution is being applied through the fence row nozzles.




FIG 4.45

IV. OPERATING INFORMATION




FIG 4.46

Solution Quick-Fill

To fill the solution tank, make sure the sump valve under the tank is open. To access the front fill, pull the front fill latch lever down and the assembly will lower (fig. 4.46). Connect it to your solution supply (fig. 4.47, item 2) and fill to the desired level. You may also fill the rinse tank from ground level (fig. 4.47, item 1) with owner supplied connection. When finished, shut the valves and return the front fill to the locked position. See the next page for information regarding the use of the side fill inductor (fig. 4.48) for filling the solution tank.



FIG 4.47



FIG 4.48

IV. OPERATING INFORMATION

Inductor Operation

With the engine running and the parking brake set, flip the lock switch up (fig.4.49 item 1). Lower the inductor assembly with the inductor control box switch (fig. 4.49, item 2). If filling with the suck-on attachment, leave the engine running. If filling with the push-on attachment, turn the en-

gine off.

Load water only: B-connected, C- on, E-off, F-off.

Suck water only*: B-connected,C-on, E-off, F-off.

Load water/induct chem: B-connected, E-open, F-off.

Suck water/induct chem*: B-connected,E-open, F-off.

Fill rinse tank: A-handle perpendicular to sprayer.

Rinse inductor tank with rinse tank: F- valve on.

Rinse inductor tank with nurse tank (suck or load): F-valve on, E-valve on.

*To activate “suck-on” pump, flip the inductor control switch up (fig. 4.49, item 3). This will start the pump. Flip switch down when filling is complete.

NOTE:

The following fill and rinse scenarios refer to figure 4.50 below.




FIG 4.49




FIG 4.50

IV. OPERATING INFORMATION

AGITATION SYSTEM



FIG 4.51

The speed of the sparge agitation system is controlled by a variable flow solution valve mounted on the solution pump (fig. 4.51). The agitation switch (fig. 4.52) on the right-hand console controls the rate of flow through the sparge system. While watching the indicator on the sparge valve (fig. 4.53), increase or decrease the flow rate with the agitation control switch. Press up to increase flow rate and down to decrease it. When desired rate of flow is achieved, release the agitation switch.



FIG 4.52



FIG 4.53

IV. OPERATING INFORMATION




FIG. 4.54



FIG 4.55

Foamer Operation

To operate the foam marking system, locate the toggle switch on the top of the hydrostat control handle (fig. 4.54). Push the top of the switch left if foam is desired from the left foam drop. Push the top of the switch right if foam is desired from the right foam drop. Return the switch to the middle position if no foam is desired.

System pressure is indicated by a pressure gauge on the regulator which is mounted next to the foam tank (fig. 4.55). To adjust the air pressure in the foam tank, turn the knob on the regulator clockwise for more pressure, and counterclockwise for less pressure. To correctly decrease the pressure in the foam tank, you must first open either the left or right foam valve for a moment to relieve system pressure. Then adjust regulator accordingly.

See figure below for foam drop valve configurations.




FIG 4.56

IV. OPERATING INFORMATION

Filling Foam Marker System




FIG 4.57

CAUTION

Before performing any service or refilling of the foam marker, shut the engine off and relieve system pressure from the tank.

WARNING

DO NOT stand directly over or in front of valves when opening.

Relieve pressure from the foam tank by opening the ¼" ball valve on the side of the foam tank (fig 4.57, item 2). Close the ball valve after pressure is relieved. Open the top 2" ball valve (fig. 4.57, item 1). Add water to the tank, leaving enough room for the foam concentrate. Next add the foam concentrate according to the label on the container. After filling is complete, close the 2" ball valve on top of the tank. Start the sprayer's engine and adjust the air pressure accordingly (see previous page).

IV. OPERATING INFORMATION



FIG 4.58



FIG 4.59

NOTE:

Select a safe area to rinse spray system and clean sprayer where the chemicals will not drift off to contaminate people, animals, vegetation, or water supply.

NOTE:

Refer to chemical manufacturer's guide for types of cleaning solution combinations (plain water, cleaning agents, etc.).

Rinse System Operation

NOTE:

Activate the rinse system only after solution tank is empty.

TO RINSE SOLUTION TANK AND 3" FILL LINES:

Solution pump is controlled by the Raven monitor (fig. 4.58).

1. Turn on spray system monitor Turn the rate switch to the "MANUAL" position. Using the flow increase/decrease lever, increase solution pressure to maximum PSI.
2. Close the solution tank valve (fig. 4.59, item 2).
3. Depress the "SOLU TANK" rinse switch (fig. 4.59, item 3).
4. When finished rinsing the solution tank return the rinse switch back to the "OFF" position and turn the spraying system off (including solution pump switch, and monitor).

TO RINSE BOOM SUPPLY AND NOZZLES:

1. Follow steps 1 and 2 from above.
2. Turn agitation off (fig. 4.59, item 1).
3. Close solution tank valve (fig. 4.59, item 2) and open boom supply valves (fig. 4.59).
4. Depress the "BOOM" rinse switch (fig. 4.59, item 3).
5. When finished rinsing the boom return rinse switch back to the "OFF" position and turn the spraying system off (including solution pump switch, monitor, boom solution valves and main spray power switch).

IV. OPERATING INFORMATION



FIG 4.60

HAND WASH SYSTEM

NOTICE

**FILL WITH FRESH
WATER ONLY**

Fill hand wash system tank (fig. 4.60) with fresh water only. The hand wash valve is located under the left side of the sprayer (fig. 4.61). Remember to close the valve before refilling.




FIG 4.61

NOTICE

HAND WASH ONLY

IV. OPERATING INFORMATION

LIGHTS



FIG 4.62

HIGHWAY LIGHTS - Mounted on the cab and on the transom mount is two each trapezoid d head lamps (fig. 4.64, item 1 and 2). Use these lights when traveling on a public road at night. Turn them on using the rocker switch on the steering pedestal (fig. 4.62).

FIELD LIGHTS - The front of the cab also houses four trapezoidal flood lamps and two trapezoidal head lights (fig. 4.64, item 3). Use these lights when operating in a field after dark. Turn them on by pressing rocker switches located on the upper right cab headliner (4.65). Turn them off when entering a public roadway.

The highway or field lights are operational when the light switch is pushed in the up position (fig. 4.63). The ignition key does not have to be on in order to operate the highway lights but does have to be on to operate field lights. Extended use without the engine operating to charge the battery is not recommended.



FIG 4.63



FIG 4.64



FIG 4.65

IV. OPERATING INFORMATION



FIG 4.66

Work Lights

Additional work lights are located on each boom cradle (fig. 4.67, items 1 & 2), one on each side facing forward and one on each side facing backward. Use these lights when operating in a field after dark. Turn them on by pressing the rocker switch (fig. 4.66). To turn them off, press rocker switch down. Turn them off when entering a public roadway.

The ignition key does have to be on in order to operate the work lights, but extended use without the engine operating to charge the battery is not recommended.



FIG 4.67

IV. OPERATING INFORMATION




FIG 4.68

Turn Signals

To activate the front (fig. 4.69) and rear turning signals (fig. 4.70, item 1), move the turn signal lever (fig. 4.68, item 1) forward to turn right and back to turn left. Steering column-mounted turn signal indicators will correspondingly flash when either side of the turn signals is activated. The turn signal lever is not a self-centering switch; you must return it to the “OFF” position by hand after completing your turn.



FIG 4.69

Hazard/Warning Lights

To activate the flashing hazard/warning lights (fig. 4.69 & 4.70,) depress the “FLASHER” switch (fig. 4.68) Activate the hazard/warning lights anytime traveling on a public road, day or night, unless prohibited by law. Rotary warning lights are an option, (Fig 4.70A). Flasher switch will activate these lights.

Running Lights

Activating the highway lights (see page 47) will also turn on the “RED” running lights on the rear of the machine (fig. 4.70, item 2).




FIG 4.70



FIG 4.70A

IV. OPERATING INFORMATION

HAGIE STS 10 CAB



FIG 4.71

| | |
|------------------------------|----|
| Emergency Exit..... | 51 |
| Windshield Wiper/Washer..... | 52 |
| Message Center..... | 53 |

IV. OPERATING INFORMATION



FIG 4.72

Emergency Exit

Any cab glass may be broken in the event that an emergency exit is required.

1. Use the exiting tool located right rear of window frame (fig. 4.72) and break window (fig 4.73).
2. Push window outward until there is room to exit.
3. Climb out through and away from hazardous situation.



FIG. 4.73

IV. OPERATING INFORMATION



FIG 4.75

Windshield Wiper/Washer

To turn the windshield wiper on, locate the windshield wiper switch on the right side of the head liner (fig. 4.75, item 1). Depress the switch to the “ON” position. The wiper will continue to operate until the switch is returned to the “OFF” position.

To activate the windshield washer pump, depress the windshield washer switch (fig. 4.75, item 2) and hold the switch down until the desired amount of washing solution has been applied and then release the switch. Turn the wiper switch to the “OFF” position when the washing solution has been completely wiped away. Washer fluid bottle located behind cab, (fig 7.10 page 66).



FIG 4.76

Message Center

The message center in the cab of a Hagie STS 10 offers valuable information as the following (fig 4.76).

1. Tread adjust width.
2. Engine RPM
3. Engine oil pressure
4. Hour meter
5. Fuel level
6. Coolent temperature
7. Tire size
8. Battery voltage
9. Speed range
10. Program version

This information can also be viewed by using the up and down arrows.

IV. OPERATING INFORMATION

Air Suspended Seat

1- Seat Cushion Adjustment. Rotate knob to desired cushion position.

2- Height Adjustment. Pull knob out to lower seat. Push knob in to raise seat.

3- Lateral Isolator. Lift lever to engage lateral Iso-lator. Push lever down for lock-out

4- Ride Firmness Adjustment. Rotate knob counterclockwise for firm ride, clockwise for soft ride. For average ride, rotate knob to middle of travel.


5- Fore-Aft Adjustment. Pull lever out and move seat.

6- Fore-Aft Isolater. Lift lever to engage fore-aft isolater. Push lever down for lock-out.

7-Backrest Adjustment. Lift lever to stop and lean rearward or forward to adjust backrest position.

8-Armrest Tilt Adjustment. Turn counterclockwise to lower tilt, clockwise to raise tilt.


9-Lumbar Adjustment. Rotate knob clockwise to increase lumbar support, counterclockwise to decrease support.




1



2



3



4







FIG 5.87




9




8



7



5



6

V. CALIBRATION

CALIBRATING YOUR SPRAYING SYSTEM

It is important to apply chemicals as recommended by the manufacturers of the product. In order to do so, the spraying system must be properly calibrated. Determine the speed at which the sprayer will be driven while applying chemicals.

To select the best speed, consider the lay of the land, the condition of the soil, the type of crops, the height of the crops, etc. Select the nozzle spacing (distance between each nozzle on the spray boom) best suited for the intended spraying job.

For help in determining the nozzle spacing and height of boom, refer to the Spray Product Catalog that accompanies this manual. There are several types and sizes of nozzles. Select (as recommended by the catalog) and install the type and size of nozzles best suited for the intended spraying job. The type and size of nozzles selected will depend upon the speed the sprayer will travel, the nozzle spacing, and the number of gallons one intends to apply per acre.

IMPORTANT:

**DO NOT ADD CHEMICALS UNTIL
CALIBRATION IS COMPLETED.**

VERIFYING CALIBRATION

Check with manufacturer on recommended spray pressure. To test your system, fill the solution tanks with clean water. Do not add chemicals until calibrated and verified.

With brakes applied, start the engine of the sprayer; throttle the engine to operating speed and remain parked. Turn on all boom section solution

switches. Make sure there are no leaks and that all nozzles are spraying a desirable pattern. Continue spraying in the stationary position for at least 10 minutes for proper warm-up of the sprayer and its system. Catch one nozzle's spray for one minute in an adequately sized and marked container.

V. CALIBRATION

The measured flow rate should be the same as the flow rate shown on the chart below. The chart shows rate of discharge in gallons per minute for various field speeds and row spacings to apply 10 gallons per acre.*

If the measured flow rate is not the same as that on the calibration tube's chart, consult the

trouble shooting guide in the service manual for the spray system's monitor.

All nozzles should be spraying at about the same flow rate. If one drives the sprayer at the proper speed and maintains the right pressure setting while spraying, the desired gallons per acre will be applied.

RATE OF DISCHARGE

| Tip Spacing | GALLONS PER MINUTE** | | | | |
|-------------|----------------------|-------|-------|-------|-------|
| | 4 mph | 5 mph | 6 mph | 7 mph | 8 mph |
| 15" | .101 | .126 | .151 | .176 | .202 |
| 16" | .107 | .133 | .160 | .187 | .214 |
| 17" | .114 | .142 | .171 | .199 | .228 |
| 18" | .121 | .151 | .181 | .211 | .242 |
| 19" | .127 | .158 | .190 | .222 | .254 |
| 20" | .134 | .167 | .201 | .234 | .268 |
| 30" | .201 | .251 | .303 | .351 | .403 |
| 36" | .242 | .302 | .363 | .423 | .484 |
| 38" | .255 | .318 | .382 | .446 | .510 |
| 40" | .269 | .336 | .403 | .470 | .538 |

* Divide by 10 to get 1 gallon per acre rate

** At a rate of 10 gallons per acre

VI. TRANSPORTING

A. DRIVING

When driving the sprayer on a public road or highway, drive carefully and follow these steps.

1. Always have the booms in the folded position and cradled when driving or transporting.
2. Flashing hazard/warning lights have been placed on the sprayer to warn other drivers.
3. Know and obey all state laws for driving farm equipment on a public road or highway.
4. Adjust the sprayer's speed to suit the conditions.
5. Slow down and use turn signals before turning.
6. Pull over to the side road before stopping.
7. Keep a proper lookout, and maintain control of the sprayer.
8. Do not drive under trees, bridges, wires or other obstructions unless there is clearance.
9. Use extra care before entering or leaving a public road or highway.
10. A SMV (Slow Moving Vehicle) emblem has been mounted on the sprayer to warn other drivers that one is moving slowly. Keep it properly displayed, unless prohibited by law.

B. TRAILERING:

NOTE:

Extra care should be taken when loading the sprayer onto any trailer. Consider whether it is best to back the sprayer on or drive the sprayer forward.

1. Loading:

WARNING

**Never load or unload a sprayer
with solution in the tanks.**

NOTE:

Be sure to read and understand the trailer's owner and operator manual. Hitch the trailer to the pulling vehicle as shown in the trailer's owner and operator manual.


VI. TRANSPORTING

When moving the sprayer onto a trailer, follow these steps completely:

- a. Pull the trailer to flat ground. Apply the pulling vehicle's parking brake and turn off the engine. Use tire chocks to keep the trailer from moving.
- b. Fold in the sprayer's booms and lower to the boom cradle.
- c. Lower the trailer ramps and set the ramp spacing for the sprayer's tread setting.
- d. Get someone to help guide you onto the trailer. Keep everyone a safe distance from the sprayer.




- e. Allow enough room between the sprayer and the pulling vehicle for turning.
- f. Secure the sprayer to the trailer. See the trailer's owner and operator manual for instructions.
- g. Cover or remove the SMV (Slow Moving Vehicle) emblem when traveling over 25 miles per hour.



2. Unloading:

When moving the sprayer off of a trailer, follow these steps completely:

- a. Pull the trailer to flat ground. Apply the pulling vehicle's parking brake and turn off the engine. Use tire chocks to keep the trailer from moving.
- b. Lower the trailer ramps and set ramp spacing for the sprayer's tread setting.
- c. Release securing restraints carefully.
- d. Get someone to help guide off the trailer. Keep everyone a safe distance from the sprayer.
- e. Uncover or replace the SMV (Slow Moving Vehicle) emblem.



VII. SERVICE AND MAINTENANCE

| PAGE NO | Service Point | C L E A N | C H A N G E | C H E C K | G R E A S E | D R A I N |
|---------|---|-----------------------|----------------------------|-----------------------|----------------------------|-----------------------|
| 62 | ENGINE OIL | | A | DAILY | | |
| 64 | RADIATOR COOLANT LEVEL | | | DAILY | | |
| 64 | COOLANT CONCENTRATION | | AS REQ | 500 HRS* | | |
| 68 | RADIATOR GRILLE SCREEN | DAILY | | | | |
| 74 | ENGINE DRIVE BELT | | AS REQ | DAILY | | |
| 74 | A/C COMPRESSOR BELT | | AS REQ | 250 HRS | | |
| 66 | A/C COMPRESSOR | | B | | | |
| 70 | FUEL FILTER (WATER SEPARATOR) | | 500 HRS* | | | DAILY |
| 70 | IN-LINE FUEL STRAINER | | AS REQ | | | |
| 67 | AIR INTAKE FILTER | NOT REC | C | | | |
| 67 | FILTER MINDER® | | D | DAILY | | |
| 62 | HYDRAULIC RESERVOIR OIL LEVEL | | 500HRS** | DAILY | | |
| 68 | HYDRAULIC CHARGE and SUCTION FILTER (1 in tank) | | E | | | |
| 69 | SOLUTION LINE STRAINER | AS REQ | | DAILY | | |
| 63 | TORQUE HUB® OIL LEVEL | | F | DAILY | | |
| 79 | WET TANK | | | | | DAILY |
| 71 | FRONT LEG STRG ZERKS (4 PLACES – 2 EACH) | | | | 50 HRS | |
| 71 | REAR LEG BRG ZERKS (2 PLACES – 1 EACH) | | | | 500 HRS* | |
| 76 | TREAD ADJUSTMENT BEARING TORQUE | | AS REQ | 50 HRS | | |
| 72 | BATTERIES | 100 HRS | AS REQ | DAILY | | |
| 75 | LUG NUT TORQUE | | | G | | |
| 80 | TIRE PRESSURE | | | 50 HRS | | |
| 70 | FRESH AIR CAB FILTER | 50 HRS | AS REQ | | | |
| 70 | CHARCOAL CAB FILTER | | AS REQ | | | |
| 70 | RECIRCULATION FILTER | | AS REQ | | | |
| 79 | SPRAY NOZZLE DIAPHRAGMS & SPRAY TIPS | | | 500HRS** | | |

*OR YEARLY, WHICHEVER COMES FIRST; OR AS REQUIRED

**OR AT THE BEGINNING OF THE SEASON, WHICHEVER COMES FIRST; OR AS REQUIRED

NOTE A: SEE ENGINE MANUFACTURER'S HAND BOOK

NOTE B: CHARGE AS REQ; USE PROPER EQUIPMENT

NOTE C: FOLLOW FILTER MINDER READINGS

NOTE D: RESET EACH TIME YOU SERVICE AIR FILTER

NOTE E: 1ST 50 HRS, THEN 250 HRS THEREAFTER

NOTE F: 1ST 50 HRS, THEN 100 HRS THEN YEARLY

NOTE G: IMMEDIATELY, THEN 50 HRS THEREAFTER

VII. SERVICE AND MAINTENANCE

SERVICE INTERVALS

Initial checks after receiving machine

IMMEDIATELY  then 

- 1) Check lug nut torque, then every 50 hours (page 75)

FIRST 50 HOURS  then 

- 1) Change Torque Hub[®] oil, then every 100 hours (page 63)
- 2) Change hydrostatic charge pressure and suction filter, then every 250 hours (page 68)

Daily 

- 1) Check engine oil (page 62)
- 2) Drain fuel filter (water separator) (page 70)
- 3) Check radiator coolant level (page 65)
- 4) Check radiator coolant (page 64)
- 5) Check engine drive belt (page 74)
- 6) Check Filter Minder[®] (page 67)
- 7) Check hydraulic oil reservoir level (page 62)
- 8) Check solution line strainer (page 69)
- 9) Drain wet tank (page 79)
- 10) Check batteries (page 72)

VII. SERVICE AND MAINTENANCE

As Required



- 1) Change coolant concentration (page 64)
- 2) Clean radiator grille screen (page 68)
- 3) Change engine drive belt (page 74)
- 4) Change A/C compressor belt (page 74)
- 5) Charge A/C compressor (page 66)
- 6) Change fuel filter (water separator) (page 70)
- 7) Change in-line fuel pre-filter (page 70)
- 8) Change hydraulic reservoir oil (page 62)
- 9) Clean solution line strainer (page 69)
- 10) Clean batteries (page 72)
- 11) Knock particles from fresh air intake cab filter (page 70)
- 12) Change fresh air intake cab filter (page 70)
- 13) Change charcoal cab filter (page 70)
- 14) Knock particles from recirculating cab filter (page 70)
- 15) Change recirculating cab filter (page 70)
- 16) Check and replace spray nozzle diaphragms and spray tip (page 79)
- 17) Change tread adjust bearing bolt torque (page 76)

VII. SERVICE AND MAINTENANCE

Every 50 HOURS



- 1) Check tire pressure (page 80)
- 2) Check lug nut torque (page 75)
- 3) Visually inspect tread adjust bearing bolts (page 76)
- 4) Grease front steering zerks (page 71)
- 5) Knock particles from fresh air intake cab filter (page 70)

Every 100 HOURS



- 1) Check Torque Hub[®] oil level (page 63)
- 2) Clean batteries (page 72)
- 3) Check tread adjust bearing bolt torque (page 76)

Every 250 HOURS



- 1) Check A/C compressor belt (page 74)
- 2) Change hydrostatic charge pressure and suction filter (page 68)

Every 500 HOURS



or



- 1) Check coolant concentration (page 64)
- 2) Change fuel filter (water separator) (page 70)
- 3) Change hydraulic reservoir oil (page 62)
- 4) Change Torque Hub[®] oil (page 63)
- 5) Check spray nozzle diaphragms and spray tips (page 79)
- 6) Grease rear leg bearing zerks (page 71)

VII. SERVICE AND MAINTENANCE

FLUIDS



FIG 7.01

Engine oil

OIL LEVEL - The engine oil level dipstick is located on the left-hand side of the engine (fig. 7.01). Never operate the engine with the oil level below the “L” (low) mark or above the “H” (high) mark. Wait at least five minutes after shutting off the engine to check the oil level; this allows time for the oil to drain to the oil pan. Check the engine oil level daily.

CAPACITY - Low to high mark capacity is 2.0 quarts. Engine oil pan capacity is 17 quarts. Refer to Engine Operation and Maintenance manual for maintenance schedule.

NOTE:

The engine must be level when checking the oil level to make sure the measurement is correct.




FIG 7.02

Hydraulic Oil Reservoir

OIL LEVEL - Check the sight gauge level on the hydraulic oil reservoir (fig 7.03) daily. Add just enough fluid so the level is in the center of the sight gauge. Always check the hydraulic oil level when it is cool. Hydraulic oil will expand when heated.

TYPE - Premium hydraulic fluids containing high quality rust/oxidation/and foam inhibitors are required. Hydraulic oil must conform to one of the following types: anti-wear hydraulic oil, type F automatic transmission fluid, or agricultural hydraulic transmission fluid. Replace the oil in the hydraulic reservoir at 500 hours or at the beginning of each spraying season, whichever comes first.

NOTE:

CLEANLINESS STANDARD: Always make sure area is clean before changing filter or hydraulic oil.



FIG 7.03

VII. SERVICE AND MAINTENANCE




FIG 7.04

Torque Hub[®] Oil

OIL LEVEL - Each Torque Hub[®] should maintain an oil level of half full at all times. Less than that would limit lubrication, and over half full could cause overheating and damage. To check oil level, position Torque Hub[®] so one of the face plugs is positioned at 12 O'clock (fig. 7.04, item 1). The other plug will be either at 9 O'clock or 3 O'clock (fig. 7.04, item 2). Remove the lower plug: if no oil comes out, oil level is too low. Check Torque Hub[®] oil level every 100 hours.

If EP-90 oil is needed, remove the top plug also and fill just until it starts to come out the lower hole. With the oil at a satisfactory level, re-install plugs.

CHANGE - The Torque Hub[®] oil should be changed after the first 50 hours of operation, preferably in a loaded condition. Subsequently, it should be changed every 500 hours after that, or once a year whichever comes first.

To change the Torque Hub[®] oil, position one of the plugs at 6 O'clock, and the other at either 3 O'clock or 9 O'clock. Remove the bottom plug to drain the oil. Once all of the oil is drained, re-install the bottom plug and remove the top plug. Refill Torque Hub[®] with EP-90 oil as described above.

GENERAL MAINTENANCE - If your sprayer is going to sit for an extended period of time, occasionally rotate the hubs by driving the sprayer forward or backward a few feet to adequately coat all internal hub parts. This will prevent rusting if moisture inadvertently entered the hub during an oil change. Failure to rotate hub and disperse oil may cause rusting and internal damage.

VII. SERVICE AND MAINTENANCE



FIG 7.05



FIG 7.06

| Ethylene Glycol | | |
|-----------------|-------|-------|
| 40% | -23°C | -10°F |
| 50% | -37°C | -34°F |
| 60% | -54°C | -65°F |

FIG 7.07

Cooling System

COOLANT TYPE - Your cooling system should always be sufficiently charged with an adequate mixture of antifreeze and water, regardless of the climate, in order to maintain a broad operating temperature range. Your cooling system has been factory-charged with an ethylene glycol-based antifreeze.

NOTE:

Ethylene glycol-based antifreeze and propylene glycol-based antifreeze should never be mixed.

CHECKING CONCENTRATION - The radiator cap is located toward the rear of the engine compartment (fig. 7.05). Never remove a cap from a hot engine. Always allow the engine to cool before servicing cooling system.

A 50/50 antifreeze/water mixture is a conservative mixture which allows good protection against both overheating and freezing. If a stronger antifreeze mixture is required, be sure not to exceed the engine manufacturer's guidelines for antifreeze mixing. The table in figure 7.07 gives a few examples of ethylene glycol antifreeze/water mixture protection values. Consult the engine manufacturer's handbook for further information.

Concentration should be checked every 500 hours or at the beginning of each winter, whichever comes first. It should be checked using a refractometer; "floating ball"-type density testers or hydrometers are not accurate enough for use with heavy duty diesel cooling systems.

VII. SERVICE AND MAINTENANCE



FIG 7.08



FIG 7.09

CHANGING COOLANT - Your coolant should periodically be changed to eliminate the buildup of harmful chemicals. Drain and replace the coolant every other spraying season or every 1,000 hours of operation, whichever comes first. Refill only with ethylene glycol coolant. Antifreeze should be mixed only with soft water because hard water contains minerals which break down the anti-corrosion properties of antifreeze.(FIG 7.08).

Fuel

TYPE - No. 2 diesel fuel is recommended for the best economy and performance under most operating conditions. In operating conditions under 32° F, use a blend of No. 1 and No. 2 diesel fuel. The addition of No. 1 diesel fuel may cause loss of power and/or fuel economy.

STORING - See section 8 on sprayer storage.

REFILLING - Always turn off the engine and allow it to cool before refueling. Never smoke while fueling. Keep a fire extinguisher within reach while refueling.

The fuel cell on an STS 10 holds 150 gallons - do not fill it completely: fuel can expand and run over. Wipe up all spilled fuel and clean with detergent and water before starting the engine.

VII. SERVICE AND MAINTENANCE



FIG 7.09

Air Conditioning

TYPE - The cab on your sprayer is equipped with a R-134a air conditioning system.

RECHARGING - Recharge it only with R-134a refrigerant. If your air conditioning system is mistakenly charged with R-12 refrigerant, serious problems, such as compressor seizure, may result. Therefore, confirm refrigerant before recharging system.

If you do not have the proper recharging equipment, it is recommended that you allow an independent service agent service your air conditioning system.



FIG 7.10

Windshield Washer Fluid

The windshield washer reservoir is located rear of the cab (fig. 7.10). Check it occasionally and refill it from the cap inside the cab with non-freezing automotive windshield cleaner as required.

FLUID CAPACITIES AND TYPES

| | |
|--|--|
| Engine oil pan, including filter | 17 quarts SAE 15W-40 |
| Engine oil dipstick, L-H mark | 2 quarts |
| Hydraulic oil reservoir | 32 gallons anti-wear hydraulic oil |
| Hydraulic system (reservoir, lines, filter, cooler, etc)..... | 55 gallons |
| Torque Hub [®] oil level | |
| Front (2)..... | approx. 84 oz. ea. EP-90 |
| Rear (2) | approx. 62 oz. ea. EP-90 |
| Engine cooling system..... | 18 gallons ethylene glycol |
| Fuel cell..... | 150 gallons No. 1 or 2 diesel |

VII. SERVICE AND MAINTENANCE



FIG 7.12




FIG 7.13



FIG 7.14

NOTE:
Service the air cleaner before the yellow indicator reaches the red line of the Filter Minder®.

FILTERS

Engine Air Intake

LOCATION – The engine air intake filter is accessed by opening the door on the front of the engine compartment (fig. 7.12).

REMOVAL - The engine air intake filter element should only be removed if it is going to be replaced. After loosening the air cleaner clamp and removing the end cap, carefully remove the filter so as to not knock any dust off the filter and into the air intake passage (fig. 7.13). Secondary filter doesn't need to be replaced if primary is intact.

REPLACEMENT - Your sprayer is equipped with a Filter Minder® to notify you of filter element efficiency. Follow its guidelines for servicing. (See below.) At appropriate service time, install the new element carefully to ensure proper sealing.

CLEANING - It is not recommended to clean the air filter element. However, a clean damp cloth should be used to wipe dust and foreign material from the air cleaner housing. iinstalled.

NOTE:
Do not tap filter to remove dust. Engine damage may occur due to crushed filter caused by tapping. If Filter Minder® indicates restriction, remove old filter, discard and install new filter only.

Filter Minder®

LOCATION - The Filter Minder® is an air restriction monitoring system that progressively and constantly indicates how much air filter capacity remains. It is mounted on foamer bracket . (fig. 7.14). Check its reading daily.

SERVICE - Service the air cleaner when the Filter Minder® reads 20" (80% of average dirt holding capacity).

VII. SERVICE AND MAINTENANCE



FIG 7.15

Radiator Screen

In order to maintain maximum air flow through the engine cooling system's radiator, oil cooler, and air conditioning condenser, the cooling air intake grille (fig. 7.15) must be inspected often and periodically cleaned.

NOTE:

Failure to keep cooling systems clean can cause over heating and damage to the hydrostatic system and/or engine.

Compressed air will dislodge most large trash or loose dirt after the hood has been opened for service. Blow out the screen away from the machine. Water from a pressurized hose may also be used, or if necessary the screen may be soaked with soapy water and scrubbed with a brush.

NOTE:

When cleaning cooling fins of the radiator, oil cooler, or A/C condenser with compressed air or water, be careful not to damage cooling fins which may impair cooling capabilities.



FIG 7.16

Hydraulic Filter

Remove and install a new 10 Micron rated suction filter (fig. 7.16) at the end of the first 50 hours of use; subsequently, replace the filter every 250 hours, or once a year, whichever comes first.

VII. SERVICE AND MAINTENANCE



FIG 7.17

Hydraulic Tread valves

The front valve (fig 7.17) is mounted on the back of the front cross member. The rear valve is mounted on the front of the rear cross member (1.18).

Solution Line Strainer

To help maintain consistent application rates, check the solution line strainer (fig. 7.19) daily for blockage. Clean the strainer screen as required. Be sure to wear the appropriate clothing while removing and cleaning the line strainer screen. Confirm the gasket is in place before re-installing the screen.




FIG 7.18



FIG 7.19

VII. SERVICE AND MAINTENANCE



FIG 7.20

Fuel Filter

PRIMARY (WATER SEPARATOR) - (fig. 7.20) Drain water and sediment from the separator daily. Replace every 500 hours or once a year, whichever comes first.

IN-LINE STRAINER - (fig. 7.21) Note direction of fuel flow arrow when replacing.

Fresh Air Cab Filters

PAPER FILTER Filter - (fig. 7.22 item 1) .The paper filter should be cleaned every 50 hours, or more often if necessary. Remove the paper element and gently tap it against a flat surface. Direct low pressure compressed air through the filter to remove larger particles. Replace the paper filter if necessary.

CHARCOAL FILTER - (fig. 7.22 item 2) Remove and replace at the first sign of chemical odor entering the cab.

Figure 7.23 shows air tube that fresh air comes into the cab.



FIG 7.21




FIG 7.22



FIG 7.23

VII. SERVICE AND MAINTENANCE




FIG 7.24

LUBRICATION Steering Bearings

Grease zerks are located on the “tie rod” ball pivot (fig. 7.24, item 1) and steering plate (fig. 7.24, item 2) of each front leg (four places total). Grease all four zerks once a week or every 50 hours, whichever comes first. To maintain bearing integrity, grease the bearing plate on each rear leg every 500 hours or once a year, whichever comes first.

Grease front and rear leg towers (fig. 7.25 item 1 and 2), daily. DO NOT USE AIR TYPE GREASE GUN TO LUBE LEG TOWERS< MAY RESULT IN SEAL DISTORTION.



FIG 7.25

VII. SERVICE AND MAINTENANCE

ELECTRICAL

Batteries

SAFETY

CAUTION

Batteries contain sulfuric acid. Avoid contact with skin, eyes, or clothing. Do not inhale fumes or ingest liquid. Batteries contain gases which can explode. Keep sparks and flame away while servicing.

SERVICE ACCESS - The batteries are located at the rear of

the machine behind battery service access panel (fig. 7.26).



FIG 7.26

NOTE:

When servicing the electrical system always disconnect the batteries. Remove the ground cable first and connect it last.

NOTE:

To ensure the best electrical contact, battery terminal connections should be as clean and as tight as possible.



FIG 7.27

Install replacement batteries with ratings equivalent to or higher than the specs below.

VOLTAGE 12 V (only)

CCA (30 sec. at 0° F)..... 950

RESERVE CAPACITY 185 min.
at 25 amps

CLEANING - Disconnect battery cables from batteries.

Remove all corrosion with a wire brush or battery post brush. Wash the cable connections and battery posts with a weak solution of baking soda or ammonia. Apply dielectric or grease to prevent future corrosion. Reconnect the cables to the batteries making sure they are tight. Clean every 100 hours.

CHARGING - To ease charging of the batteries, there is a

set of auxiliary battery charging posts on the rear of the sprayer's mainframe (fig. 7.27). Connect your charging cables to them just as you would to the battery, positive cable to positive terminal, and negative cable to negative terminal. Keep these terminals clean and their caps in place when not in use.

VII. SERVICE AND MAINTENANCE



FIG 7.28

Circuit Breakers

The Hagie STS 10 has circuit breaker and fuse systems located in various locations. Under right hand console, (fig. 7.28) for the cab functions, under the cab, (fig 7.31) for the light functions and engine compartment, (fig. 7.30) for the engine functions. (Figure 7.29A shows the decal for the cab fuses, circuit breakers and relays) . Figure 7.29B shows power ports for add on radios.

Refer to the Hagie STS 10 Parts Manual for specific information regarding correct breaker location and size.




FIG 7.29A



FIG 7.31



FIG 7.29B



FIG 7.30

VII. SERVICE AND MAINTENANCE




FIG 7.31




FIG 7.32




FIG 7.33

BELTS

Engine Drive Belt

REMOVAL - Insert a 3/8 inch square ratchet drive (fig. 7.31) into the belt tensioner (fig. 7.32, item 1) and lift upward to remove the belt (fig. 7.32, item 2).

INSPECTION - Visually inspect the belt daily. Check the belt for intersecting cracks (fig. 7.33). Transverse (across the belt width) cracks are acceptable. Longitudinal (direction of belt length) cracks that intersect with transverse cracks are not acceptable. Replace the belt if it is frayed or has pieces of material missing.

A/C Compressor Belt

To tighten air conditioner compressor belt, loosen the two pivot bolts (fig. 7.34, item 1) and the two slide bolts (fig. 7.34, item 2). Using a suitable prying tool, adjust tension on belt to desired tautness. While maintaining tension, re-tighten all four bolts. Inspect belt ever 250 hours.




FIG 7.34

VII. SERVICE AND MAINTENANCE

BOLT TORQUE

Wheel Bolts



FIG 7.35

Keep wheel bolts tight.
See owner's manual for
torque specifications.

To install wheel and tire assembly on the Torque Hub[®], lubricate studs with anti-seize grease. Align the wheel bolt holes with the Torque Hub[®] studs and mount the wheel on the hub.

NOTE:

To achieve even torquing consistency, the tire should be completely off the ground.




FIG 7.36

Start all of the lug nuts on and tighten them until they are just snug. Following the torque sequence in (fig. 7.36), first turn each lug nut to a torque value of 120 dry foot-pounds. Use slow, even pressure on the torque-wrench. Quick or jerky movements cause inaccurate values. Repeat the same sequence to 150 dry foot-pounds and again finally 400 to 500 dry foot-pounds.

CAUTION

Check lug nut torque immediately after receiving machine and every 50 hours thereafter.

If the wheel turns during lug nut torquing, lower the machine to the ground just enough for the tire to touch and prevent rotation or more preferably, place a suitable wedge between the tire and the ground.

Lower the machine and resume operation. Recheck torque after 30 minutes of operation.

VII. SERVICE AND MAINTENANCE




FIG 7.37




FIG 7.38

NOTE:

If hydraulic tread adjustment will never be operated on your machine, set all bearing bolt torque settings to 50 foot-pounds and continue inspection as above without adjustment test.

Bearing Torque on Hydraulic Tread Adjust Equipped Units

With the engine turned off, visually inspect the tread bearing bolts on both the bottom and side (fig. 7.37) every 50 hours. Torque check them every 100 hours.

To torque check the bearing bolts:

1. Loosen the jam nut (fig. 7.37, item 2) on each bearing bolt.
2. Using a criss-cross or "X" pattern (fig. 7.38), verify current torque on each bolt (fig. 7.37, item 1) is equivalent to last check from 100 hours previous (repeat torque pattern a second time).
3. Then increase the torque two foot-pounds on each bolt using the "X" pattern and retighten each jam nut.
4. Start the sprayer and test the hydraulic tread adjustment (see page 26). If the tread still adjusts smoothly see next step. If the tread does not move skip to step 6.
5. Repeat steps 1 and 3 until the tread does not move.
6. Reduce torque setting to last value that allowed the tread to operate freely, retighten jam nuts and resume operation.

NOTE:

Never operate the unit with the tread bearing bolt torque set below 25 foot-pounds. If the bolt torque has to be loosened to 25 foot-pounds in order for the hydraulic tread adjust to work freely, call Hagie Customer Support.

VII. SERVICE AND MAINTENANCE

TOE-IN

To correctly gauge toe-in, use a tape measure placed at one-half tire height on the front center seam of the front tire compared to the same measurement of the rear of the front tire (subtract the front measurement from the rear measurement - it must be a positive number). Correct toe-in should fall somewhere between one half and three quarters of an inch.

Toe-in is pre-set at the factory and should not have to be adjusted unless the steering cylinders are removed.

Difficulty steering one way versus the other may also indicate incorrect toe-in and may require adjustment. For further assistance regarding toe-in measurement and adjustment, contact the Hagie Customer Support Department.

NOTE:

See page 78 for instructions on adjusting toe-in. See also page 26 for information on recalibrating self-centering cylinders.




FIG 7.39

VII. SERVICE AND MAINTENANCE

TOE-IN ADJUSTMENT



FIG 7.40

To adjust the toe-in of the front tires follow these instructions for both front steering cylinders carefully:

1. Loosen jam nut (fig. 7.41, item 3).
2. Move left and right tires evenly until difference in dimension "A" and "B" (fig. 7.42) are within specified range. At least one wheel must be parallel with the frame.
3. Screw swivel assembly in or out on steering cylinder until the swivel joint lines up with steering plate.
4. Insert bolt through swivel joint and steering plate, and tighten jam nut.



FIG 7.41

NOTE:

Dimension "A" should be $\frac{1}{2}$ " to $\frac{3}{4}$ " less than dimension "B." For more information regarding toe-in, see page 77.




FIG 7.42

VII. SERVICE AND MAINTENANCE

SPRAY SYSTEM

Spray Tips

At the beginning of each season, or as required, remove a random sample of spray tip caps (fig. 7.43, item 3) and inspect the nozzle tips. If they are plugged or worn, clean or replace them.

Nozzle Diaphragms

At the beginning of each spray season, remove each nozzle body cap (fig. 7.43, item 1) and inspect the diaphragm for wear or fit (fig. 7.43, item 2). Replace if necessary. Refer to accompanying manual containing nozzle information.

Calibration

See pages 54-55 on spray system calibration.

Winter Storage

See page 83 on cold weather storage of spray system.




FIG 7.43

FOAM MARKER SYSTEM

Wet Tank

To prevent system condensation from contaminating the engine air compressor, remove moisture from the wet tank daily by pulling on its drain cord (fig. 7.44).

Winter Storage

See page 83 on storage of foamer system.



FIG 7.44

VII. SERVICE AND MAINTENANCE



FIG 7.45



FIG 7.46




FIG 7.47

TIRES

Air Pressure

Check tire pressure once a week or every 50 hours of operation (fig. 7.45). Never inflate a tire more than the recommended maximum air pressure. Use an air line with a locking air chuck and stand behind tire tread while filling (fig. 7.46).

NOTE:

Tire pressure will depend on load quantity and type in solution tanks. Refer to page 19 for tire specifications.

WARNING

When inflating tire use extension hose with in-line air gauge and clip-on air chuck, which allow operator to stand clear of tire side wall explosion trajectory.

Wheel Bolts

See page 75 for recommended wheel bolt torque specifications and torquing pattern.

Mounting

If you do not have proper mounting equipment, let your local qualified tire sales/service dealer mount the tire for you. Tire should be mounted on rim according to (fig. 7.47), for best traction and tread cleaning action.

Toe-In

See pages 77-78 for information regarding toe-in measurement and adjustment.

VII. SERVICE AND MAINTENANCE

DAILY INSPECTION

| Inspection Point | Action (if necessary) |
|--|-----------------------------|
| Check | |
| Engine oil level..... | Add oil |
| Radiator coolant level..... | Add antifreeze solution |
| Engine drive belt | Replace belt |
| Filter Minder® | Replace air filter element |
| Hydraulic reservoir oil level | Add hydraulic oil |
| Solution line strainer..... | Remove and clean |
| Batteries | Clean and/or tighten |
| Radiator grille screen | Clean |
| Look for loose or missing items such as shields | Tighten or replace |
| Look for any fluid leaks pooled on machine or ground | Determine cause and correct |
| Drain | |
| Fuel/water separator | See page 70 |
| Wet tank..... | See page 79 |

VIII. STORAGE

A. Preparing the sprayer for storage.

1. Perform daily level checks, lubrication, and bolt and linkage inspections as required in this manual in section eight on maintenance.
2. Every other season, drain the coolant from the engine and radiator. Probe the drain holes during draining to ensure they are not clogged by sludge, scale, or other deposits. Fill the cooling system to the top with a 50/50 water/antifreeze mixture. Run engine to operating temperature and re-check level.

NOTE:

If antifreeze is added, make sure the engine is then run to operating temperature to assure proper mixing of solution.

3. Add a fuel stabilizer to the fuel and fill fuel tank.
4. Run the engine until it is at operating temperature, then drain the engine oil. Refill with fresh oil of recommended weight and install a new lubricating oil filter element.
5. With the engine at normal operating temperature, cycle all hydraulic functions including the steering.
6. Release tension on all belts. For more detailed information, consult the manufacturer's handbook that accompanies this manual.
7. Use plastic bags and water-resistant adhesive tape to seal the air intake opening, all exhaust manifold openings, engine oil filler cap, hydraulic oil tank breather cap, and fuel tank caps.
8. Disconnect and remove battery or batteries. Completely clean and charge the batteries. Coat the terminals with dielectric grease and store battery in cool, above freezing dry place.
9. Thoroughly clean the sprayer. Touch up any painted surfaces that are scratched or chipped. For touch-up paint recommendations contact the Hagie Manufacturing Customer Support Department.
10. Replace worn or missing decals. See pages 8-12 for proper location of warning decals and their corresponding part number. Warning decals and all other Hagie decals are available through the Hagie Manufacturing Customer Support Department.

NOTE:

For replacement decals contact:
Hagie Manufacturing Company
Box 273, Clarion, IA 50525
Ph. 1-800-247-4885

VIII. STORAGE

11. Use a multi-purpose grease to coat exposed hydraulic cylinder rods.
12. To winterize the spray system, it is recommended that you use an environmentally-safe type antifreeze and water mixture that will give you adequate protection to minus 30 degrees below zero. Drain any remaining solution in the system and run the antifreeze mixture through the spray system until it comes out all boom openings. Repeat the above process with both the foam marker and rinse systems.
13. If the sprayer must be stored outside, cover it with a waterproof cover.

B. Removing the sprayer from storage.

1. Inspect the condition, and test the air pressure, of all tires. Please see page 80 for information regarding proper tire maintenance.
2. Carefully unseal all openings that were sealed in the storage process.
3. Clean and reinstall the battery. Be sure to attach the battery cables to the proper terminals.
4. Tighten all belts. Inspect and replace any worn belts. For information on belts, see page 74.
5. Check engine oil, hydraulic oil, and engine coolant levels; add, if necessary. A mixture of 50/50 antifreeze and water will cool adequately in summer as well as protect in winter.

NOTE:

Protective compounds such as grease can harden under exposure to weather conditions.

6. Completely clean the sprayer.
7. Review section 7 on maintenance (pages 58-81), and perform all needed services as instructed.
8. For starting instructions, see pages 20-21 in section 4 on operating information.

NOTE:

See Warranty on page 93 concerning **improper storage**.

IX. TROUBLE SHOOTING

A. ENGINE

| |
|---|
|  CAUTION Start engine from operator's seat only. When running engine in a building, be sure there is adequate ventilation. |
|---|

| PROBLEM | POSSIBLE CAUSE | SUGGESTED REMEDY |
|--------------------|--|---|
| Engine won't crank | Dead battery Poor battery connections Starter or starter relay Blown fuse in engine electric box | Recharge or replace battery Clean and tighten Test; rebuild or replace Check 20amp fuse |
| Engine won't start | Out of fuel Clogged fuel filter Cold weather Low starter speed Blown fuse in engine electric box | Fill fuel tank Replace fuel filters Refer to engine manual for cold weather starting information Check starter and battery Check 20amp fuse |

IX. TROUBLE SHOOTING

| PROBLEM | POSSIBLE CAUSE | SUGGESTED REMEDY |
|---|--|--|
| Engine overheats | <p>Engine overloaded</p> <p>Dirty radiator core or dirty grill screen</p> <p>Faulty radiator cap</p> <p>Loose or faulty fan belt</p> <p>Faulty thermostat</p> <p>Low coolant level</p> | <p>Reduce load</p> <p>Remove all foreign material and clean all items</p> <p>Replace cap</p> <p>Tighten or replace fan belt</p> <p>Replace thermostat</p> <p>Refill to proper level with recommended coolant</p> |
| Engine misfires: runs uneven, low power | <p>Water in fuel</p> <p>Dirty air cleaner element</p> <p>Poor grade of fuel</p> <p>Fuel tank vent clogged</p> <p>Clogged fuel filter</p> | <p>Drain, flush, replace filter, fill system</p> <p>Replace element</p> <p>Drain system; change to good grade</p> <p>Open fuel tank vent in cap</p> <p>Replace fuel filter</p> |
| Engine knocks | <p>Low oil level in crankcase</p> <p>Cold engine</p> | <p>Add oil to full mark</p> <p>Allow proper warm-up period; refer to engine owner's handbook</p> |

NOTE:

For additional engine information, consult engine manufacturer's manual.

IX. TROUBLE SHOOTING

B. SPRAY SYSTEM

 **WARNING**
CHEMICALS ARE DANGEROUS
Read The Chemical manufacturer's labels to avoid injury or damage.

| PROBLEM | POSSIBLE CAUSE | SUGGESTED REMEDY |
|-----------------------------------|---|---|
| Solution pump will not prime | Low water level in pump Air leak in suction line Solution tank valve closed | Make sure the solution tank is not empty, solution pump is self-priming Inspect and tighten all fittings on suction line Open solution tank valve, allowing air to leave the system |
| Erratic reading on pressure gauge | Orifice in back of gauge clogged Faulty gauge Air leak in suction line Glycerin leaking from gauge | Remove gauge; clean orifice; re-install Replace gauge Inspect and tighten all fittings in suction line Replace gauge |

IX. TROUBLE SHOOTING

| PROBLEM | POSSIBLE CAUSE | SUGGESTED REMEDY |
|---|--|---|
| Solution pump not producing normal pressure | Clogged line strainer screen | Remove screen; clean thoroughly; tighten strainer cap to avoid air leak |
| | Air leak in suction flow to pump | Inspect and tighten all fittings on suction line |
| | Restricted solution flow to pump | Main solution tank shut-off valve not completely open |
| | Suction hose collapsed | Obstruction at inlet end of hose, causing high vacuum on hose |
| | Faulty hydraulic pump | Replace hydraulic pump |
| | Faulty hydraulic motor on solution pump | Replace motor |
| | Internal restriction of diaphragm such as build up of chemical | Disassemble; inspect; clean; reassemble |
| Malfunction of electric solution valve | Faulty ground | Clean and tighten ground |
| | Dirty contact terminals | Clean contact terminals |
| | Separation in wire | Check continuity and replace wire |
| | Faulty switch | Replace switch |
| | Short in solenoid coil | Replace valve |
| | Bad valve | Replace valve |

NOTE:

If your unit is equipped with a high-pressure system, call the Hagie Manufacturing Customer Support Department for possible causes and suggested remedies.

IX. TROUBLE SHOOTING

C. HYDROSTATIC SYSTEM



CAUTION

DO NOT GO NEAR LEAKS. High pressure oil easily punctures skin causing injury, gangrene, or death. If injured, seek emergency medical help. Immediate surgery is required to remove oil. Do not use finger or skin to check for leaks. Lower load or relieve hydraulic pressure before loosening fittings.

| PROBLEM | POSSIBLE CAUSE | SUGGESTED REMEDY |
|---|--|--|
| Machine won't move in either direction | Engine speed too low Oil level in reservoir low Clogged filter Hydrostatic pump not turning Faulty hydrostatic pump Air leak in suction line Low charge pressure Cruise is set to low | Set engine at operating RPM before trying to move machine Fill reservoir to proper level w/ approved oil; see section on Service and Maintenance Replace filter Check drive coupling Replace pump Inspect and tighten all fittings on suction line See section under charge pressure Adjust knob for cruise |
| Machine will move in only one direction | Faulty high pressure relief valve Cruise set to low | Switch relief valves from side to side; If problem reverses, replace multi-function valve (Call Hagie Customer Support and refer to parts manual) |

IX. TROUBLE SHOOTING

| PROBLEM | POSSIBLE CAUSE | SUGGESTED REMEDY |
|--------------------------------------|---|--|
| Hydrostatic system responding slowly | <p>Engine speed too low</p> <p>Oil level in reservoir low</p> <p>Cold oil</p> <p>Plugged filter</p> <p>Partially restricted suction line</p> <p>Internal damage</p> | <p>Set engine at operating RPM before trying to move machine</p> <p>Fill reservoir to proper level with approved oil; see section on Service and Maintenance</p> <p>Allow for adequate warm-up period</p> <p>Check and replace filter</p> <p>Inspect for collapsed suction hose</p> <p>Replace hydrostatic pump or motor</p> |
| Noisy hydrostatic system | <p>Cold oil</p> <p>Low engine speed</p> <p>Oil level in reservoir low</p> <p>Air in system</p> <p>Internal damage to pump</p> | <p>Allow for adequate warm-up period</p> <p>Increase engine speed</p> <p>Fill reservoir to proper level with approved oil; see section on Service and Maintenance</p> <p>Inspect and tighten all fittings on suction line</p> <p>Replace pump</p> |
| External oil leaks | <p>Loose or faulty fittings</p> <p>Damaged O-ring</p> <p>Faulty hose</p> | <p>Tighten or replace</p> <p>Inspect; if damaged replace</p> <p>Replace hose</p> |

IX. TROUBLE SHOOTING

D. HYDRAULIC SYSTEM



CAUTION

DO NOT GO NEAR LEAKS. High pressure oil easily punctures skin causing injury, gangrene, or death. If injured, seek emergency medical help. Immediate surgery is required to remove oil. Do not use finger or skin to check for leaks. Lower load or relieve hydraulic pressure before loosening fittings.

| PROBLEM | POSSIBLE CAUSE | SUGGESTED REMEDY |
|---|--|--|
| Entire hydraulic system fails to function | <p>Oil level in reservoir low</p> <p>Oil not reaching pump</p> <p>Faulty hydraulic pump</p> | <p>Fill reservoir to proper level with approved oil; see section on Service and Maintenance</p> <p>Prime the pump by removing four bolts holding hydraulic filter flange to hydraulic tank, put clean oil in until hoses are full. Cleanliness is a standard. Call the Hagie Customer Support for further instruction.</p> <p>Replace hydraulic pump</p> |
| Noisy hydraulic pump | <p>Collapsed suction hose caused by cold oil</p> <p>Oil level in reservoir low</p> <p>Air leak in suction line</p> | <p>Allow for adequate warm-up period</p> <p>Fill reservoir to proper level with approved oil; see section on Service and Maintenance</p> <p>Inspect and tighten all fittings on suction hose</p> |

IX. TROUBLE SHOOTING

E. ELECTRICAL

 CAUTION
 Batteries contain sulfuric acid. Avoid contact with skin, eyes, or clothing. Do not inhale fumes or ingest liquid. Batteries contain gases which can explode. Keep sparks and flame away while servicing.

NOTE:
 Disconnect battery when servicing any part of electrical system to prevent system damage.

| PROBLEM | POSSIBLE CAUSE | SUGGESTED REMEDY |
|--|---|---|
| Entire electrical system is dead Ignition switch is off | Dead battery Poor battery connection Low charging rate No charging rate Master switch | Charge or replace Clean and tighten Tighten alternator belt Replace alternator |
| Light system does not function | Poor ground Burned-out bulb Separation or short in wire Blown fuse Faulty switch | Clean and tighten ground Replace bulb Check continuity and replace wire Replace fuse Replace switch |

IX. TROUBLE SHOOTING

NOTES

X. LIMITED WARRANTY

1. The Warranty

- a. This warranty gives you specific legal rights. You may also have other rights which may vary from state to state.
- b. Hagie makes this warranty only to the original purchaser of its new equipment.
- c. The warranty period ends 12 months from the date of delivery of equipment to the original purchaser. When requesting warranty service, the original purchaser must present evidence of the date of delivery of the equipment.
- d. Parts or rebuilt assemblies furnished under the terms of this warranty are not warranted beyond the original warranty period.
- e. Exceptions to this warranty must be covered by separate warranty agreements.

2. Items not covered by Hagie Warranty

- a. Used equipment.
- b. Tires, tubes, engines, and batteries (under separate manufacturer's warranty).
- c. Depreciation or damage caused by normal wear, accident, improper maintenance, improper storage, or improper use.
- d. Service calls and transporting the equipment to and from the place where the warranty work is performed.

3. Unapproved service or modification

NOTE:

All obligations of Hagie Manufacturing Company under this warranty shall be terminated if:

- a. . . . service is performed by someone other than Hagie authorized personnel.
or
- b. . . . the equipment is modified or altered without Hagie approval.

4. No commercial loss coverage

- a. Hagie shall not be liable for incidental or consequential damages or injuries (damage and repairs of equipment itself, loss of profits, rental or substitute equipment, loss of good will, etc.).
- b. SOME STATES DO NOT ALLOW THE EXCLUSION OR LIMITATION OF INCIDENTAL OR CONSEQUENTIAL DAMAGES, SO THE ABOVE LIMITATION MAY NOT APPLY TO YOU.

5. Merger clause

- a. The entire warranty agreement is included in this writing.
- b. Any oral agreements that are made by the selling persons about the equipment are not warranties, and are not to be relied upon by the purchaser.

6. No representations or implied warranty

- a. The parties agree that the implied warranties of merchantability and fitness for a particular purpose and all other warranties expressed or implied, are excluded from this transaction and shall not apply to the equipment sold.

INDEX

| | PAGE | | PAGE |
|---------------------------------|-------|--|------|
| A | | F | |
| Air Conditioning System | | Fence Row | |
| Belt | 74 | L.E.D. Indicator | 39 |
| Cab Filters | | Operation | 39 |
| Fresh Air Intake | 70 | Switch | 39 |
| Charcoal | 70 | Filter Minder® | 67 |
| Recirculation | 70 | Filters | |
| Charging System | 66 | Cab | 70 |
| Air Suspended Seat | 53 | Engine Air Intake Filter | 67 |
| Agitation System | 42 | Fuel Filter | 70 |
| Antifreeze | 64 | Hydraulic Charge Pressure Filter | 68 |
| B | | Hydraulic High-Pressure In-Line Filter | 69 |
| Batteries | | Hydraulic Suction Filters | 68 |
| Charging Auxiliary Posts | 72 | Solution Line Strainer | 69 |
| Service Access | 72 | Radiator Grille Screen | 68 |
| Belts | | Fluid Capacities | 66 |
| Engine | | Fluids | |
| Removal | 74 | Air Conditioning Charge | 66 |
| Inspection | 74 | Cooling System Coolant | 64 |
| A/C Compressor | 74 | Engine Oil | 62 |
| Boom | | Fuel | 65 |
| Configuring 80' to 90' | 34 | Hydraulic Oil | 62 |
| Cradling | 33 | Torque Hub® Oil | 63 |
| Operation | 28-34 | Windshield Washer | 66 |
| C | | Foam Marking System | |
| Cab | 50 | Adjusting System Pressure | 43 |
| Emergency Exit | 51 | Operation | 43 |
| Filters | | System Pressure Gauge | 43 |
| Charcoal Filter | 70 | Wet Tank | 79 |
| Fresh Air Intake Filter | 70 | Fuel Filter | 70 |
| Recirculation Filter | 70 | H | |
| Calibration | | High Pressure In-Line Filter | 69 |
| Monitor54 | | Hydraulic Tread Adjust | |
| Testing | 54-55 | Bearing Adjustment | 76 |
| Circuit Breakers | 73 | Operation | 26 |
| Cooling System | | Tread Width Indicators | 26 |
| Coolant | 64 | Hydrostatic Drive System | 23 |
| Radiator Grille Screen | 68 | L | |
| E | | L.E.D. Indicators | |
| Electrical System | | Boom Solution Valve | 37 |
| Batteries | | Fence Row Nozzle | 39 |
| Charging Auxiliary Posts | 72 | Lights | |
| Service Access | 72 | Field Lights | 47 |
| Circuit Breakers | 73 | Hazard/Warning Lights | 49 |
| Engine | | Highway Lights | 47 |
| Fuel | 65 | Running Lights | 49 |
| Filter | 70 | Turn Signal | 49 |
| Oil | 62 | Work Lights | 48 |
| Operation | 21-22 | | |

NOTES
